

# Dirigible Balloons

This ebook is for the use of anyone anywhere in the United States and most other parts of the world at no cost and with almost no restrictions whatsoever. You may copy it, give it away or re-use it under the terms of the [Project Gutenberg License](https://www.gutenberg.org/license) included with this ebook or online at <https://www.gutenberg.org/license>. If you are not located in the United States, you'll have to check the laws of the country where you are located before using this ebook.

Title: Dirigible Balloons

Author: Charles B. Hayward

Release Date: September 18, 2020 [eBook #63234]

Language: English

\*\*\* START OF THIS PROJECT GUTENBERG EBOOK DIRIGIBLE BALLOONS \*\*\*

Produced by James Simmons.

This file was produced from page images at the Internet Archive.

### Transcriber's Note

This book was transcribed from scans of the original found at the Internet Archive. I have rotated some images. The caption for Figure 20 was illegible in the scanned pages so I used a description from a paragraph that referred to it.

# DIRIGIBLE BALLOONS

## INSTRUCTION PAPER

PREPARED BY  
CHARLES B. HAYWARD

MEMBER, SOCIETY OF AUTOMOBILE ENGINEERS; MEMBER, THE  
AERONAUTICAL SOCIETY;  
FORMERLY SECRETARY, SOCIETY OF AUTOMOBILE ENGINEERS;  
FORMERLY  
ENGINEERING EDITOR, "THE AUTOMOBILE"

AMERICAN SCHOOL OF CORRESPONDENCE  
CHICAGO ILLINOIS  
U.S.A.

COPYRIGHT, 1912, 1918, BY  
AMERICAN SCHOOL OF CORRESPONDENCE  
COPYRIGHTED IN GREAT BRITAIN  
ALL RIGHTS RESERVED



# DIRIGIBLE BALLOONS

## INTRODUCTION

Of the first attempts of men to emulate the flight of birds, we have no knowledge, but one of the earliest, perhaps, is embodied in the myth of Icarus and Daedalus. Xerxes, it is said, possessed a throne which was drawn through the air by eagles. The Chinese have sometimes been given credit for the invention of the balloon, as they have for many other scientific discoveries. It is related that a balloon was sent up at Pekin in celebration of the ascension of the throne by an emperor in the beginning of the fourteenth century.

[image]

*Fig. 1. De Lana Airboat.*

**Early Attempts.** Leonardo da Vinci devoted some time to the problem of artificial flight. His sketches show the details of batlike wings which were to spread out on the downward stroke and fold up with the upward stroke.

Francisco de Lana planned to make a flying ship the appearance of which was somewhat like that shown in Fig. 1, by exhausting the air from metal spheres fastened to a boat. The boat was to be equipped with oars and sails for propulsion and guiding. The method in which he purposed to create the vacuum in the spheres consisted of filling them with water, thus driving out the air, then letting the water run out. He thought that if he closed the tap at the proper time, there would be neither air nor water in the spheres. His flying ship was never constructed, for he piously decided that God would never permit such a change in the affairs of men.

**The First Flying Machine.** In 1781, Meerwein of Baden, Germany, constructed a flying machine, and was the first, perhaps, to intelligently take into

account the resistance of the air. He took the wild duck as a basis of calculation, and found that a man and machine weighing together 200 pounds would require a wing surface of from 125 to 130 square feet. It is of interest to note that Lilienthal, who met his death in trying to apply these principles, over one hundred years later found these figures to be correct. Two views of Meerwein's apparatus are shown in Fig. 2. The construction involved two wood frames covered with cloth. The machine weighed 56 pounds and had a surface area of 111 square feet. The operator was fastened in the middle of the under side of the wings, and over a rod by which he worked the wings. His attempts at flight were not successful, as his ideas of the power of a man were in error.

[image]

*Fig. 2. Meerwein Flying Machine*

**Classification.** All attempts at human flight have gone to show that there are four possible ways in which man may hope to navigate the air. He may imitate the flight of birds with a machine with moving or flapping wings; he may use vertical screws or helices to pull himself up; he may use an aeroplane and sail the air like an eagle; or, lastly, he may raise himself by means of a gas bag and either drift with the wind or move forward by means of propellers.

In these attempts, apparatus of several different types has been developed. The types are classed in two general divisions based on their weight relative to that of the atmosphere, viz, the *lighter-than-air machines* and the *heavier-than-air machines*. Lighter-than-air machines are those which employ a bag filled with a gas whose specific gravity is sufficiently less than that of the air to lift the bag and the necessary attachments from the earth, and include simple balloons and dirigibles. Heavier-than-air machines, which will neither rise nor remain in the air without motive power, include all forms of aeroplanes.

## SIMPLE BALLOONS

**Theory.** The balloon-like airship has been more highly developed than any other type of aerial craft, probably because it offers the most obvious means of overcoming the force of gravitation. It depends on the law of Archimedes:

*"Every body which is immersed in a fluid is acted upon by an upward force, exactly equal to the weight of the fluid displaced by the immersed body."*

That is, a body will be at rest if immersed in a fluid of equal specific gravity or equal weight, volume for volume; if the body has less specific gravity than the



fluid in which it is immersed it will rise; if it has a greater specific gravity it will sink. Therefore, if the total weight of a balloon is less than the weight of all the air it displaces it will rise in the air. It is, then, necessary to fill the balloon with some gas whose specific gravity is enough less than, that of the air to make the weight of the gas itself, the bags, and the attachments, less than the weight of the air displaced by the whole apparatus. The gases usually employed are *hydrogen*, *coal gas*, and *hot air*.

At atmospheric pressure and freezing temperature, the weight of a cubic foot of air is about .08 pound; the weight of a cubic foot of hydrogen is about .005 pound, under the same conditions. According to the law of Archimedes, a cubic foot of hydrogen would be acted upon by a force equal to the difference, or approximately .075 pound, tending to move it upwards. In the same way, a cubic foot of coal gas, which weighs .04 pound, would be acted upon by an upward force of .04 pound.

It is evident, then, that a considerable volume of gas is required to lift a balloon with its envelope, net, car, and other attachments.

Further, it requires almost twice as much coal gas as hydrogen, under the same conditions, for we have seen that the upward force on it is only half as great. The lifting power of hot air is less than one-eighth as great as that of hydrogen at the highest temperature that can possibly be used in a balloon.

[image]

*Fig. 3. Montgolfier Balloon*

The general type of lighter-than-air machines may be divided into *aerostats* (ordinary balloons, which are entirely dependent on wind currents for lateral movement, and which are often the chief features at country fairs) and dirigible balloons or *aeronats* (air swimmers). Dirigible balloons employ the gas bag for maintaining buoyancy, and have rudders to guide them and propellers to drive them forward through the air in much the same way that ships are driven through the water.

**The First Balloon.** For several years, Joseph and Steven Montgolfier had been experimenting with a view to constructing a balloon: in the first place by filling bags with *steam*; then by filling bags with *smoke*, and finally by filling bags with *hydrogen*. These attempts were all failures, for the steam rapidly condensed and the smoke and hydrogen leaked through the pores in the bags. They finally hit upon the idea of filling the bag with *hot air*, by means of a fire under its open mouth. Several balloons were burned up, but the next was always made larger,

until, at their first public exhibition on June 5, 1783, the bag had become over 35 feet in diameter. On this occasion, it rose to a height of between 900 and 1,000 feet, but the hot air was gradually escaping, and at the end of ten minutes the balloon fell to the ground.

The Montgolfiers then went to Paris, where, after suffering the loss of a paper balloon by rain, they sent up a waterproofed linen one carrying a sheep, a duck, and a rooster in a basket. A rupture in the linen caused the three unwilling aeronauts to make a landing at the end of about ten minutes. The Montgolfiers received great honor, and small balloons of this type became a popular fad. One of these balloons is shown in Fig. 3, making an ascension.

**Rozier.** The first man to go up in a balloon was Rozier, who ascended in a captive balloon to a height of about 80 feet, in the latter part of the year 1783. Later, in company with a companion, he made a voyage in a free balloon, remaining in the air about half an hour. In these balloons, the air within was kept hot by means of a fire carried in a pan immediately below the mouth of the bag, as shown in Fig. 4. Accidents were numerous on account of the fabric becoming ignited from the fire in the pan.

[image]

*Fig. 4. Rozier Hot-Air Balloon*

**Improvements by Charles.** The physicist, Charles, was working along these lines at the same time. He coated his balloon with a rubber solution to close up the pores, and was thereby enabled to substitute hydrogen for the hot air. Shortly after the Montgolfiers' first public exhibition, Charles sent up his balloon for the benefit of the *Academie des Sciences* in Paris. The balloon, which weighed about 19 pounds, ascended rapidly in the air and disappeared in the clouds, where it burst and fell in a suburb of the city. The impression produced upon the peasants at seeing it fall from the heavens was hardly different from what could be expected. They believed it to be of devilish origin, and immediately tore it into shreds. Charles subsequently built a large balloon quite similar to those in use today. A net was used to support the basket, and a valve, operated by means of ropes from the basket, was arranged at the top to permit the gas to escape as desired.

**The Balloon Successful.** The English Channel was first crossed in 1785. Blanchard, an Englishman, and Jeffries, an American, started from Dover on January 7 in a balloon equipped with wings and oars. After a very hazardous voyage, during which they had to cast overboard everything movable to keep

from drowning, they landed in triumph on the French coast.

An attempt to duplicate this feat was made shortly afterward by Rozier. He constructed a balloon filled with hydrogen, below which hung a receiver in which air could be heated. He hoped to replace by the hot air the losses due to leakage of hydrogen. Soon after the start the balloon exploded, due to the escaping gas reaching the fire, and Rozier and his companion were dashed on the cliffs and killed.

## EARLY DIRIGIBLES

**Meusnier the Pioneer.** The fact that the invention of the dirigible balloon and means of navigating it were almost simultaneous is very little known today and much less appreciated. Like the aeroplane, its development was very much retarded by the lack of suitable means of propulsion, and the actual history of what has been accomplished in this field dates back only to the initial circular flight of La France in 1783. Still the principles upon which success has been achieved were laid down within a year of the appearance of Montgolfier's first gas bag. Lieutenant Meusnier, who subsequently became a general in the French army, must really be credited with being the true inventor of aerial navigation. At a time when nothing whatever was known of the science, Meusnier had the distinction of elaborating at one stroke all the laws governing the stability of an airship, and calculating correctly the conditions of equilibrium for an elongated balloon, after having strikingly demonstrated the necessity for this elongation. This was in 1781 and Meusnier's designs and calculations are still preserved in the engineering section of the French War Office in the form of drawings and tables.

But as often proved to be the case in other fields of research, his efforts went unheeded. How marvelous the establishment of these numerous principles by one man in a short time really is, can be appreciated only by noting the painfully slow process that has been necessary to again determine them, one by one, at considerable intervals and after numerous failures. Through not following the lines which he laid down, aerial navigation lost a century in futile groping about; in experiments absolutely without method or sequence.

[image]

*Fig. 5. Meusnier Dirigible Balloon*

Meusnier's designs covered two dirigible balloons and that he fully appre-

ciated the necessity for size is shown by the dimensions of the larger, which unfortunately was never built. This was to be 260 feet long by 130 feet in diameter, in the form of an ellipse, the elongation being exactly twice the diameter. In other words, a perfect ellipsoid, which was a logical and, in fact, the most perfect development of the spherical form. Although increased knowledge of wind resistance and the importance of the part it plays has proved his relative dimensions to be faulty, a study of the principal features of his machine shows that he anticipated the present-day dirigible of the most successful type at practically every point, barring, of course, the motive power, as there was absolutely nothing available in that day except human effort. As the latter weighs more than one-half ton per horse-power, it goes without saying that Meusnier's balloon would have been dirigible only in a dead calm.

He adopted the elongated form, conceived the girth fastening, the triangular or indeformable suspension, the air balloonet and its pumps, and the screw propeller, all of which are to be found in the dirigibles of present-day French construction, Fig. 5. It need scarcely be added that the French have not only devoted a greater amount of time and effort to the development of the dirigible than any other nation, but have also met with the greatest success in its use. It was not until 1886, or more than a century after Meusnier had first elaborated those principles, that their value became known. They were set forth by Lieutenant Letourne, of the French engineers, in a paper presented to the *Academie des Sciences* by General Perrier.

In one form or another, the salient features of Meusnier's dirigible will be found embodied in the majority of attempts of later days. His large airship was designed to consist of double envelope, the outer container of which was to provide the strength necessary, and it was accordingly reinforced by bands. The inner envelope was to provide the container for the gas and was not called upon to support any weight. This inner bag or balloon proper was designed to be only partially inflated and the space between, the two was to be occupied by air which could be forced into it at two points at either end, by pumps, so as to maintain the pressure on the gas bag uniform regardless of the expansion or contraction of its contents. Here in principle was the air balloonet of today. Instead of employing a net to hang the car from the outer envelope, the former was attached by means of a triangular suspension system fastened to a heavy rope band, or girth, encircling the outer envelope. At the three points where the lifting rope members met, a shaft running the length of the car and carrying what Meusnier described as "revolving oars" was installed. These constituted the prototype of the screw propeller, invented for aerial navigation at a time long antedating the use of steam for marine use. Thus he devised: (1) The air balloonet to husband the gas supply and thus prevent the deformation of the outer container or support, as well as

to provide stability; (2) the triangular suspension to attain longitudinal stability; and (3) the screw propeller for propulsion, beside selecting the proper location for the latter.

## PROBLEMS OF THE DIRIGIBLE

**Ability to Float.** If ability to rise in the air depended merely upon a knowledge of the principle that made it possible, it undoubtedly would have been accomplished many centuries ago. As already mentioned, Archimedes established the fact that a body upon floating in a fluid displaces an amount of the latter equal in weight to the body itself, and upon this theory was formulated the now well-known law, that every body plunged into a fluid is subjected by this fluid to a pressure from below, equivalent to the weight of the fluid displaced by the body. Consequently, if the weight of the latter be less than that of the fluid it displaces, the body will float. It is by reason of this that the iron ship floats and the fish swims in water. If the weight of the body and the displaced water be the same, the body will remain in equilibrium in the water at a certain level, and if that of the body be greater, it will sink. All three of these factors are found in the fish, which, with the aid of its natatory gland, can rise to the surface, sink to the bottom, or remain suspended at different levels. To accomplish these changes of specific gravity, the fish fills this gland with air, dilating it until full, or compressing and emptying it. In this we find a perfect analogy to the air balloonet of the dirigible, which serves the same purposes. The method by which lifting power is obtained in the dirigible is exactly the same as in the case of the balloon.

But once in the air, a balloon is, to all intents and purposes, a part of the atmosphere. There is absolutely no sensation of movement, either vertically or horizontally. The earth appears to drop away from beneath and to sweep by horizontally, and regardless of how violently the wind may be blowing, the balloon is always in a dead calm because it is really part of the wind itself and is traveling with it at exactly the same speed. If it were not for the loss of lifting power through the expansion and contraction of the gas, making it necessary to permit its escape in order to avoid rising to inconvenient heights on a very warm day, and the sacrifice of ballast to prevent coming to earth at night, the ability of a balloon to stay up would be limited only by the endurance of its crew and the quantity of provisions it was able to transport. As the use of air balloonets in the dirigible takes care of this, the question of lifting power presents no particular difficulty. It is only a matter of providing sufficient gas to support the increased weight of the car, motor and its accessories, and the crew of the larger vessel, with a factor of safety to allow for emergencies, in order to permit of staying in

the air long enough to make a protracted voyage.

**Air Resistance vs. Speed.** Unless a voyage is to be governed in its direction entirely by the wind, the dirigible must possess a means of moving contrary to the latter. The moment this is attempted, resistance is encountered, and it is this resistance of the air that is responsible for the chief difficulties in the design of the dirigible. To drive it against the wind, it must have power; to support the weight of the motor necessary, the size of the gas bag must be increased. But with the increase in size, the amount of resistance is greatly multiplied and the power to force it through the air must be increased correspondingly. The law is approximately as follows:

*Where the surface moves in a line perpendicular to its plane, the resistance is proportional to the extent of the surface, to the square of the speed with which the surface is moved through the air, and to a coefficient, the mean value of which is 0.125.*

This coefficient is a doubtful factor, the figure given having been worked out years ago in connection with the propulsion of sailing vessels. Its value varies according to later experimenters between .08 and .16, the mean of the more recent investigations of Renard, Eiffel, and others who have devoted considerable study to the matter, being .08. This is dwelt upon more in detail under "Aerodynamics" and it will be noted that the values of the coefficient *K*, given here, do not agree with those stated in that article. They serve, however, to illustrate the principles in question.

In accordance with this law, doubling the speed means quadrupling the resistance of the air. For instance, a surface of 16 square feet moving directly against the air at a speed of 10 feet per second will encounter a resistance of  $16 \times 100$  (square of the speed)  $\times 0.125 = 200$  pounds pressure. Doubling the speed, thus bringing it up to 20 feet per second, would give the equation  $16 \times 400 \times 0.125 = 800$  pounds pressure, or with the more recent value of the coefficient of .08, 512 pounds pressure. The first consideration is accordingly to reduce the amount of surface moving at right angles. The resistance of a surface having tapering sides which cut through or divide the molecules of air instead of allowing them to impinge directly upon it, is greatly diminished; hence, Meusnier's principle of elongation. If we take the same panel presenting 16 square feet of surface and build out on it a hemisphere, its resistance at a speed of 10 feet per second will be exactly half, or a pressure of 100 pounds.

By further modifying this so as to represent a sharp point, or acute-angled cone, it will be 38 pounds. There could accordingly be no question of attempting to propel a spherical balloon.

It is necessary to select a form that presents as small a surface as possible to the air as the balloon advances, while preserving the maximum lifting power. But

[image]

*Fig. 6. Giffard Dirigible*

experience has strikingly demonstrated the analogy between marine and aerial practice—not only is the shape of the bow of the vessel of great importance but, likewise, the stern. The profile of the latter may permit of an easy reunion of the molecules of air separated by the former, or it may allow them to come together again suddenly, clashing with one another and producing disturbing eddies just behind the moving body. To carry the comparison with a marine vessel a bit further, the form must be such as to give an easy "shear," or sweep from stem to stern.

[image]

*Fig. 7. De Lome Dirigible*

That early investigators appreciated this is shown by the fact that Giffard in 1852, Fig. 6, De Lome in 1872, Fig. 7, Tissandier in 1884, and Santos-Dumont in his numerous attempts, adopted a spindle-shaped or "fusiform" balloon. In other words, their shape, equally pointed at either end, was symmetrical in relation to their central plan. However, that the shape best adapted to the requirements of the bow did not serve equally well for the stern, was demonstrated for the first time by Renard, to whom credit must be given for a very large part of the scientific development of the dirigible. Almost a century earlier, Marey-Monge had laid down the principle that to be successfully propelled through the air, the balloon must have "the head of a cod and the tail of a mackerel." Nature exemplifies the truth of this in all swiftly moving fishes and birds. Renard accordingly adopted what may best be termed the "pisciform" type, viz, that of a dis-symmetrical fish with the larger end serving as the bow; and the performances of the Renard, Lebaudy, and Clement-Bayard airships have shown that this is the most advantageous form.

The pointed stern prevents the formation of eddies and the creation of a partial vacuum in the wake which would impose additional thrust on the bow. Zeppelin has disregarded this factor by adhering to the purely cylindrical form with short hemispherical bow and stern, but it is to be noted that while other German investigators originally followed this precedent, they have gradually abandoned it, owing to the noticeable retarding effect.

**Critical Size of Bag.** Next in importance to the best form to be given the vessel, is the most effective size—something which has a direct bearing upon its lifting power. This depends upon the volume, while the resistance is proportional to the amount of surface presented. Greater lifting power can accordingly be obtained by keeping the diameter down and increasing the length. But the resistance is also proportionate to the square of the speed, while the volume, or lifting power, varies as the cube of the dimensions of the container, so that in doubling the latter, the resistance of the vessel at a certain speed is increased only four times while its lifting capacity is increased eight times. Consequently the larger dirigible is very much more efficient than the smaller one since it can carry so much more weight in the form of a motor and fuel in proportion to its resistance to the air. As an illustration of this, assume a rectangular container with square ends 1 foot each way and 5 feet long. Its volume will be 5 cubic feet and if the lifting power of the gas be assumed as 2 pounds per cubic foot, its total lifting power will be 5 pounds. If a motor weighing exactly 5 pounds per horsepower be assumed, it will be evident that the motor which such a balloon could carry would be limited to 1 horse-power, neglecting the weight of the container.

Double these dimensions and the container will then measure 2 X 2 X 10 feet, giving a volume of 40 cubic feet, and a lifting power, on the basis already assumed, of a motor capable of producing 8 horsepower, and this without taking into consideration that as the size of the motor increases, its weight per horsepower decreases. The balloon of twice the size will thus have a motor of 8 horsepower to overcome the resistance of the head-on surface of 4 square feet, or 2 horse-power per square foot of transverse section, whereas the balloon of half the size will have only 1 horse-power per square foot of transverse section. It is, accordingly, not practicable to construct small dirigibles such as the various airships built by Santos-Dumont for his experiments, while, on the other hand, there are numerous limitations that will be obvious, restricting an increase in size beyond a certain point, as has been shown by the experience of the various Zeppelin airships.

To make it serviceable, what Berget terms the "independent speed" of a dirigible, i.e., its power to move itself against the wind, must be sufficient to enable it to travel under normally prevailing atmospheric conditions. These naturally differ greatly in different countries and in different parts of the same country. Where meteorological tables showed the prevailing winds in a certain district to exceed 15 miles an hour throughout a large part of the year, it would be useless to construct an airship with a speed of 15 miles an hour or less for use in that particular district, as the number of days in the year in which one could travel to and from a certain starting point would be limited. This introduces another factor which has a vital bearing upon the size of the vessel. Refer to the figures just



cited and assume further that by doubling the dimensions and making the airship capable of transporting a motor of 8 horse-power, it has a speed of 10 miles an hour. It is desired to double this. But the resistance of the surface presented increases as the square of the speed. Hence, it will not avail merely to double the power of the motor. Experience has demonstrated that the power necessary to increase the speed of the same body, increases in proportion to the cube of the speed, so that instead of a 16-horse-power motor in the case mentioned, one of 64 horse-power would be needed. There are, accordingly, a number of elements that must be taken into consideration when determining the size as well as the shape of the balloon.

**Static Equilibrium.** Having settled upon the size and shape, there must be an appropriate means of attaching the car to carry the power plant, its accessories and control, and the crew. While apparently a simple matter, this involves one of the most important elements of the design—that of stability. A long envelope of comparatively small diameter being necessary for the reasons given, it is essential that this be maintained with its axis horizontal. In calm air, the balloon, or container, is subjected to the action of two forces: One is its weight, applied to the center of gravity of the system formed by the balloon, its car, and all the supports; the other is the thrust of the air, applied at a point known as the center of thrust and which will differ with different designs, according as the car is suspended nearer or farther away from the balloon. If the latter contained only the gas used to inflate it, with no car or other weight to carry, the center of gravity and the center of thrust would coincide, granting that the weight of the envelope were negligible. As this naturally can not be the case, these forces are not a continuation of each other. But as they must necessarily be equal if the balloon is neither ascending nor descending, it follows that they will cause the balloon to turn until they are a continuation of each other, and in the case of a pisciform balloon, this will cause it to tilt downward. Like a ship with too much cargo forward, it would be what sailors term "down at the head."

As this would be neither convenient nor compatible with rapid propulsion, it must be avoided by distributing the weight along the car in such a manner that when the balloon is horizontal, the forces represented by the pressure above and the weight below, must be in the same perpendicular. This is necessary to insure static equilibrium, or a horizontal position while in a state of rest. To bring this about, the connections between the car and the balloon must always maintain the same relative position, which is further complicated by the fact that they must be flexible at the same time.

**Longitudinal Stability.** But the *longitudinal stability* of the airship as a whole must be preserved, and this also involves its *stability of direction*. Its axis must be a tangent to the course it describes, if the latter be curvilinear, Or parallel with

the direction of this course where the course itself is straight. This is apparently something which should be taken care of by the rudder, any tendency on the part of the airship to diverge from its course being corrected by the pilot. But a boat that needed constant attention to the helm to keep it on its course would be put down as a "cranky"—in other words, of faulty design in the hull. A dirigible having the same defect would be difficult to navigate, as the rudder alone would not suffice to correct this tendency in emergencies. Stability of direction is, accordingly, provided for in the design of the balloon itself, and this is the chief reason for adopting the form of a large-headed and slender-bodied fish, as already outlined. This brings the center of gravity forward and makes of the long tail an effective lever which overcomes any tendency of the ship to diverge from the course it should follow, by causing the resistance of the air itself to bring it back into line. However, the envelope of the balloon itself would not suffice for this, so just astern of the latter, "stabilizing surfaces" are placed, consisting of vertical planes fixed to the envelope. These form the keel of the dirigible and are analogous to the keel of the ship. Stability of direction is thus obtained naturally without having constant recourse to the rudder, which is employed only to alter the direction of travel.

The comparison between marine and aerial navigation must be carried even further. These vertical planes, or "keel," prevent rolling; it is equally necessary to avoid pitching—far more so than in the case of a vessel in water. So that while the question of stability of direction is intimately connected with longitudinal stability, other means are required to insure the latter. The airship must travel on an "even keel," except when ascending or descending, and the latter must be closely under the control of the pilot, as otherwise the balloon may incline at a dangerous angle. This shows the importance of an unvarying connection between the car and the envelope to avoid defective longitudinal stability. Assume, for instance, that the car is merely attached at each end of a single line. The car, the horizontal axis of the balloon, and the two supports would then form a rectangle. When in a state of equilibrium the weight and the thrust are acting in the same line. Now suppose that the pilot desires to descend and inclines the ship downward. The center of gravity is then shifted farther forward and the two forces are no longer in line.

But as the connections permit the car to swing in a vertical plane, they permit the latter to move forward and parallel with the balloon, thus forming a parallelogram instead of a rectangle. This causes the center of gravity to shift even farther, and as one of the most serious causes of longitudinal stability is the movement of the gas itself, it would also rush to the back end and cause the balloon to "stand on its head." As the tendency of the gas is thus to augment any inclination accidentally produced, the vital necessity of providing a suspension

that is incapable of displacement with relation to the balloon is evident. Here is where the importance of Meusnier's conception of the principle of triangular suspension comes in. Instead of being merely supported by direct vertical connections with the balloon, the ends of the car are also attached to the opposite ends of the envelope, forming opposite triangles. This gives an unvarying attachment, so that when the balloon inclines, the car maintains its relative position, and the weight and thrust tend to pull each other back in the same line, or, in other words, to "trim ship."

**Dynamic Equilibrium.** In addition to being able to preserve its static equilibrium and to possess proper longitudinal stability, the successful airship must also maintain its dynamic equilibrium—the equilibrium of the airship in motion. This may be made clear by referring to the well-known expedients adopted to navigate the ordinary spherical balloon. To rise, its weight is diminished by gradually pouring sand from the bags which are always carried as ballast. To descend, it is necessary to increase the total weight of the balloon and its car, and the only method of accomplishing this is to permit the escape of some of the gas, the specific lightness of which constitutes the lifting power of the balloon. As the gas escapes, the thrust of the air on the balloon is decreased and it sinks—the ascensional effort diminishing in proportion to the amount of gas that is lost. The balloon, or the container itself, being merely a spherical bag, on the upper hemispherical half of which the net supporting the car presses at all points, the question of deformation is not a serious one. Before it assumed proportions where the bag might be in danger of collapsing, the balloon would have had to come to earth through lack of lifting power to longer sustain it. Owing to its far greater size, as well as to the form of the surface which it presents to the air pressure, such a crude method is naturally not applicable to the dirigible.

Dynamic equilibrium must take into account not only its weight and the sustaining pressure of the air, but also the resistance of the air exerted upon its envelope. This resistance depends upon the dimensions and the shape of that envelope, and in calculations the latter is always assumed to be invariable. Assume, for instance, that to descend the pilot of a dirigible allowed some of the hydrogen gas to escape. As the airship came down, it would have to pass through strata of air of constantly increasing pressure as the earth is approached. The reason for this will be apparent as the lower strata bear the weight of the entire atmosphere above them. The confined gas will no longer be sufficient to distend the envelope, the latter losing its shape and becoming flabby. As the original form is no longer retained, the center of resistance of the air will likewise have changed together with the center of thrust, and the initial conditions will no longer obtain. But as the equilibrium of the airship depends upon the maintenance of these conditions, it will be lost if they vary.

**Function of Balloonets.** In the function of balloonets is realized the importance of the principle established by Meusnier. It was almost a century later before it was rediscovered by Dupuy de Lome in connection with his attempts to make balloons dirigible. That the balloon must always be maintained in a state of perfect inflation has been pointed out. But gas is lost in descents and to a certain extent, through the permeability of the envelope. Unless it is replaced, the balloon will be only partially inflated. In view of the great volume necessary, it requires no explanation to show that it would be impossible to replace the gas itself by fresh hydrogen carried on the car. It would have to be under high pressure and the weight of the steel cylinders as well as the number necessary to transport a sufficient supply would be prohibitive. Hence, Meusnier conceived the idea of employing air. But this could not be pumped directly into the balloon to mix with the hydrogen gas, as the resulting mixture would not only still be as inflammable as the former alone, but it would also contain sufficient oxygen to create a very powerful and infinitely more dangerous explosive. This led to the adoption of the *air balloonet*.

In principle the balloonet consists of dividing the interior of the envelope into two cells, the larger of which receives the light gas while the smaller is intended to hold air and terminates in a tube extending down to a pump in the car. In other words, a fabric partition adjacent to the lower part of the envelope inside and subject to deformation at will. In actual practice it consists of a number of independent cells of this kind, longitudinally disposed along the lower half of the interior of the envelope.

When the balloon is completely inflated with hydrogen, as at the beginning of an ascent, these balloonets lie flat against the lower part of the envelope, exactly like a lining. As the airship rises, the gas expands owing to the reduction in atmospheric pressure at a higher altitude, as well as to the influence of heat. With the increase in pressure, uniform inflation is maintained by the escape of a certain amount of gas through the automatic valves provided for the purpose. Unless this took place, the internal pressure might assume proportions placing the balloon in danger of blowing up. To avoid this, a pressure gauge communicating with the gas compartment is one of the most important instruments on the control board of the car, and should its reading indicate a failure of the automatic valves, the pilot must reduce the pressure by operating a hand valve. But as the car descends, the increased external pressure causes a recontraction of the gas until it no longer suffices to fill the envelope. To replace the loss the air pumps are utilized to force air into the air balloonets until the sum of the volumes of gas and air in the different compartments equals the original volume. In this manner, the initial conditions, upon which the equilibrium of the airship is based, are always maintained.

This is not the only method of correcting for change in volume, nor of maintaining the longitudinal stability of the whole fabric, the importance of which has already been detailed, but experience has shown that it is the most practical. It is possible to give the balloon a rigid frame over which the envelope is stretched and to attach the car by means of a rigid metal suspension, as in the various Zeppelin airships, or to take it semi-rigid, as in the Gross, another German type in which Zeppelin's precedent was followed only in the case of the suspension. To prevent deformation by this means, the balloon is provided with an absolutely rigid skeleton of aluminum tubes. This framing is in the shape of a number of uniform cylindrical sections, or gas compartments, each one of which accommodates an independent balloon, while over the entire frame a very strong but light fabric constituting the outer or protecting envelope is stretched taut. The idea of the numerous independent balloons is to insure a high factor of safety as the loss of the entire contents of two or three of them through accident would not dangerously affect the lifting power of the whole. The numerous wrecks which attended the landings of these huge non-flexible masses during the early stages of their development led to the provision of some form of shelter wherever they were expected to land. Even now, they are practically unmanageable in the air during a fierce wind and must be allowed to sail under control until the wind has spent itself.

The system of air balloonets has accordingly been adopted by every other designer, in variously modified forms, as illustrated by the German dirigible Parseval, in which but two air bags were employed, one at either end. They were interconnected by an external tube to which the air-pump discharge was attached, and were also operated by a counterbalancing system inside the gas bag, by means of which the inflation of one balloonet, as the after one, for example, caused the collapse of the other.

*Influence of Fish Form of Bag.* But a condition of dynamic equilibrium can not be obtained with the combined aid of the precautions already noted to secure longitudinal stability and that of the air balloonet in maintaining uniform inflation. Why this is so will be clear from a simple example. If a simple fusiform or spindle-shaped balloon be suspended in the air in a horizontal plane, the axis of which passes through its center of gravity, it would be practically pivoted on the latter and would be extremely sensitive to influences tending to tilt it up or down. It would be in a state of "indifferent" longitudinal equilibrium. As long as the axis of the balloon remains horizontal and the air pressure is coincident with that axis, it will be in equilibrium, but an equilibrium essentially unstable. Experiment proves that the moment the balloon inclines from the horizontal in the slightest degree, there is a strong tendency for it to revolve about its center of gravity until it stands vertical to the air current, or is standing straight up and

down. This, of course, refers to the balloon alone without any attachments. Such a tendency would be fatal, amounting as it does to absolute instability.

If instead of symmetrical form, tapering toward both ends, a pisciform balloon be tried, it will still evidence the same tendency, but in greatly diminished degree. This is not merely the theory affecting its stability but represents the findings of Col. Charles Renard, who undoubtedly did more to formulate the exact laws governing the stability of a dirigible than any other investigator in this field. His data is the result of a long and methodically carried out series of experiments. In the case of the pisciform balloon, the disturbing effect is due in unequal degree, to the diameter of the balloon and its inclination and speed, whereas the steadying effect depends upon the inclination and diameter, but not on the speed. The disturbing effect, therefore, depends solely on the speed and augments very rapidly as the speed increases. It will, accordingly, be apparent that there is a certain speed for which the two effects are equal, and beyond which the disturbing influence, depending on speed, will overcome the steadying effect.

To this rate of travel, Renard applied the term "critical speed," and when this is exceeded the equilibrium of the balloon becomes unstable. To obtain this data, keels of varying shapes and dimensions were submitted to the action of a current of air, the force of which could be varied at will. In the case of the *La France*, the first fish-shaped dirigible, the critical speed was found to be 10 meters, or approximately 39 feet per second, a speed of 21.6 miles per hour, and a 24-horse-power motor suffices to drive the airship at this rate of travel. But the internal combustion motor is now so light that a dirigible of this type could easily lift a motor capable of generating 80 to 100 horse-power. With this amount of power, its theoretic speed would be 50 per cent greater, or 33 miles an hour. But this could not be accomplished in practice as long before it was reached the stability would become precarious. As Colonel Renard observed in the instance just cited, "If the balloon were provided with a 100-horse-power motor, the first 24 horse-power would make it go and the other 76 horse-power would break our necks."

*Steadying Planes.* It is accordingly necessary to adopt a further expedient to insure stability. This takes the form of a system of rigid planes, both vertical and horizontal, located in the axis of the balloon and placed a considerable distance to the rear of the center of gravity. With this addition, the resemblance of the after end of the balloon to the feathering of an arrow is apparent, while its purpose is similar to that of the latter. For this reason, these steadying planes have been termed the *empennage*, which is the French equivalent of "arrow feathering," while its derivative *empennation* is employed to describe the counteraction of this disturbing effect. In the *La France*, which measured about 230 feet in length by 40 feet in diameter, the area of the planes required to accomplish this

was 160 square feet, and the planes themselves were placed almost 100 feet to the rear of the center of gravity. By referring to the illustrations of the various French airships, the various developments in the methods of accomplishing this will be apparent.

[image]

*Fig. 8. La Ville de Paris Showing Balloonets*

In the Lebaudy balloon, it took the form of planes attached to the framework between the car and the balloon. In *La Patrie* and *La Republique*, the resemblance to the feathered arrow was completed by attaching four planes in the form of a cross directly to the stern of the balloon itself. But as weight, no matter how slight, is a disturbing factor at the end of a long lever, such as is represented by the balloon, Renard devised an improvement over these methods by conceiving the use of hydrogen balloonets as steadying planes. The idea was first embodied in *La Ville de Paris*, Fig. 8, in the form of cylindrical balloonets, and as conical balloonets on the *Clement-Bayard*. These balloonets communicate with the gas chamber proper of the balloon and consequently exert a lifting pressure which compensates for their weight, so that they no longer have the drawback of constituting an unsymmetrical supplementary load.

**Location of Propeller.** The final factor of importance in the design of the successful dirigible is the proper location of the propulsive effort with relation to the balloon. Theoretically, this should be applied to the axis of the balloon itself, as the latter represents the greater part of the resistance offered to the air. At least one attempt to carry this out in practice resulted disastrously, that of the Brazilian airship *Pax*, while the form adopted by Rose, in which the propeller was placed between the twin balloons in a plane parallel with their horizontal axes, was not a success. In theory, the balloon offers such a substantial percentage of the total resistance to the air that the area of the car and the rigging were originally considered practically negligible by comparison. Actually, however, this is not the case. Calculation shows that in the case of any of the typical French airships mentioned, the sum of the surface of the suspending rigging alone is easily the equivalent of 2 square meters, or about 21 square feet, without taking into consideration the numerous knots, splices, pulleys, and ropes employed in the working of the vessels, air tubes communicating with the air balloonets, and the like. Add to this equivalent area that of the passengers, the air pump, other transverse members and exposed surfaces, and the total will be found equivalent to a quarter or even a third of the transverse section of the balloon itself.

To insure the permanently horizontal position of the ship under the combined action of the motor and the air resistance, a position of the propeller at a point about one-third of the diameter of the balloon below its horizontal axis will be necessary. Without employing a rigid frame like that of the Zeppelin and the Pax, however, such a location of the shaft is a difficult matter for constructional reasons. Consequently, it has become customary to apply the driving effort to the car itself, as no other solution of the problem is apparent. This accounts for the tendency common in the dirigible to "float high forward," and this tilting becomes more pronounced in proportion to the distance the car is hung beneath the balloon. The term "deviation" is employed to describe this tilting effect produced by the action of the propeller. Conflicting requirements are met with in attempting to reduce this by bringing the car closer to the balloon as this approximation is limited by the danger of operating the gasoline motor too close to the huge volume of inflammable gas. The importance of this factor may be appreciated from the fact that if the car were placed too far from the balloon, the propulsive effect would tend to hold the latter at an angle without advancing much, owing to the vastly increased air resistance of the much larger surface thus presented.

**Relations of Speed and Radius of Travel.** The various factors influencing the speed of a dirigible have already been referred to, but it will be apparent that the radius of action is of equally great importance. It is likewise something that has a very direct bearing upon the speed and, in consequence, upon the design as a whole. It will be apparent that to be of any great value for military or other purposes, the dirigible must possess not only sufficient speed to enable it to travel to any point of the compass under ordinarily prevailing conditions of wind and weather but also to enable it to remain in the air for some time and cover considerable distance under its own power.

*Total Weight per Horsepower Hour.* As is the case in almost every point in the design of the dirigible, conflicting conditions must be reconciled in order to provide it with a power plant affording sufficient speed with ample radius of action. It has already been pointed out that power requirements increase as the *cube of the speed*, making a tremendous addition necessary to the amount of power to obtain a disproportionately small increase in velocity. In this connection there is a phase of the motor question that has not received the attention it merits up to the present time. The struggle to reduce weight to the attainable minimum has made weight per horsepower apparently the paramount consideration—a factor to which other things could be sacrificed. And this is quite as true of aeroplane motors as those designed for use in the dirigible. But it is quite as important to make the machine go as it is to make it rise in the air, so that the question of *total weight per horsepower hour* has led to the abandonment of extremely light engines requiring a great deal of fuel.



Speed is quite as costly in an airship as it is in an Atlantic liner. To double it, the motor power must be multiplied by 8, and the machine must carry 8 times as much fuel. But by cutting the power in half, the speed is reduced only one-fifth. The problem of long voyages in the dirigible is, accordingly, how to reconcile best the minimum speed which will enable it to make way effectively against the prevailing winds, with the reduction in power necessary to cut the fuel consumption down to a point that will insure a long period of running.

When the speed of the dirigible is greater than that of the prevailing wind, it may travel in any direction; when it is considerably less, it can travel only with the wind; when it is equal to the speed of the latter, it may travel at an angle with the wind—in other words, tack, as a ship does, utilizing the pressure of the contrary wind to force the ship against it. But as the air does not offer to the hull of the airship, the same hold that water does to that of the seagoing ship, the amount of leeway or drift in such a manoeuver is excessive. This applies quite as much to the aeroplane as it does to the dirigible.

## FRENCH DIRIGIBLES

**The First Lebaudy.** The interest evidenced by the German War Department in Zeppelin's airship was more than duplicated by that aroused in French military circles by the success of the Lebaudy Brothers. Since 1900 these two brothers had been experimenting with dirigible balloons. Their first dirigible—built by the engineer Juillot—made thirty flights, in all but two of which it succeeded in returning to its starting point. This machine was somewhat similar to the later types built by Santos-Dumont and carried a 40-horsepower Daimler motor. A speed of 36 feet per second, or about 25 miles per hour, was obtained. During tests in the summer of 1904, the balloon was dashed against a tree and almost entirely destroyed.

**Lebaudy 1904.** The next year the "Lebaudy 1904" appeared. This was 190 feet long and had a capacity of 94,000 cubic feet of gas. The air bag was divided into three parts and contained 17,600 cubic feet of air. It was supplied with air from a fan driven by the engine, and an auxiliary electric motor and storage battery were carried to drive the fan when the gas engine was not working. The storage battery was also used to furnish electric lights for the airship. A horizontal sail of silk was stretched between the car and the gas bag, which had an area of something over 1,000 square feet, and a sort of keel of silk was stretched below it. A horizontal rudder, shaped like a pigeon's tail, was used at the rear, and immediately behind it were two V-shaped vertical rudders. A small vertical sail was carried, which could be used to assist in guiding the airship. The car was

16 feet long and was rigidly hung 10 feet below the bag. It was provided with an inverted pyramid of steel tubes meeting at an apex below the car to prevent injury in alighting. Sixty-three ascents were made in 1904 with this balloon, all of them comparatively successful, the longest being a journey of 60 miles in two hours and forty-five minutes.

[image]

*Fig. 9. La Patrie, French War Dirigible*

The next year a new and larger balloon equipped with a more powerful motor was used. Many flights were made in tests for the French War Department.

**La Patrie.** La Patrie was then built for the French government by the Lebaudy Brothers and was of the same design as their earlier airships. In speed it was nearly equal to Zeppelin's, and its dirigibility was nearly perfect. Fig. 9 shows a view of this airship in flight.

It was 200 feet long, and the 70-horsepower engine drove two propellers. It could carry seven people and one-half ton of ballast. It carried four people at a speed of 30 miles per hour. On its last trip it covered 175 miles in seven hours. A few days afterward, a heavy wind tore it away from its moorings and it was blown out to sea and lost.

**La Republique and Le Jaune.** Two more airships of the same type, La Republique and Le Jaune, followed this. These were tried by the French government, in 1908, and both proved successful. La Republique is illustrated in Fig. 10. The shape and equipment of the car are shown in Fig. 11. The automobile type of radiator may be seen attached to the side of the car. During a flight in the fall of 1909, a propeller blade broke and was thrown clear through the balloon envelope, causing the balloon to fall from a height of 500 feet. The four officers who formed the crew of the dirigible were killed instantly.

**Clement-Bayard II.** The numerous factors that must be considered in the design of a successful dirigible balloon as well as the many conflicting conditions that must be reconciled have already been referred to in detail. How these are carried out in practice may best be made clear by a description of what may be considered as an advanced type of dirigible, the Clement-Bayard II, Fig. 12, of French design, and the most successful of the French military air fleet. Its predecessor, the Clement-Bayard I, Fig. 13, made thirty voyages, some of them of considerable distances, without suffering any damage, but a study of its shortcomings led to their elimination in the following model.

The pisciform shape of the first Clement-Bayard was retained but given

[image]

*Fig. 10. La Republique, French War Dirigible*

[image]

*Fig. 11. Car of La Republique*

more taper, the dimensions being 248.6 feet overall by 42.9 greatest diameter, this being but a short distance back of the bow. This gives it a ratio of length to diameter of 5.76. The gas balloonet stabilizers were eliminated altogether, Fig. 12. The total gas capacity is approximately 80,000 cubic feet. Like all French dirigibles it is of the true flexible type, the only rigid construction being that of the framework of the car itself. To the latter are attached all rudders and stabilizing devices, instead of making them a part of the envelope as formerly. The latter is made of continental rubber cloth.

[image]

*Fig. 12. Clement-Bayard II, French Dirigible*

Light steel and aluminum tubing are employed in the construction of the frame supplemented by numerous piano-wire stays. This frame extends almost the entire length of the envelope and carries at its rear end a cellular, or box-kite, type of stabilizing rudder, instead of the former gas balloonets employed on the Clement-Bayard I, Fig. 13. This cellular rudder is in two parts, consisting of two units of four cells each, the two groups being joined at the top, with a space between them. In addition to acting as a stabilizer, this is also the direction rudder, its leverage being increased by making the end planes somewhat larger than the partitions of the cells. Between the cellular stabilizing rudder and the envelope is placed the horizontal rudder for ascending or descending. In the illustration this appears to be a flag, but it is in reality a long rectangular plane, which may be tilted on its longitudinal axis, the latter being at right angles to that of the balloon. There are two air balloonets of about one-third the total capacity of the balloon itself, and they are designed to be inflated by large aluminum centrifugal blowers driven from the main engines themselves.

There are two motors, each of 125 horsepower, both being of the same

[image]

*Fig. 13. Clement-Bayard I*

conventional design, *i.e.*, four cylinder four cycle vertical water cooled. In fact, they are merely light automobile motors. The cylinders have separate copper water jackets and the motors themselves are muffled, which is a departure from the usual custom. Each drives a separate propeller carried on top of the main frame through bevel gearing.

The Clement-Bayard II made itself famous by its rapid and successful flight from the suburbs of Paris across the Channel to London, in October, 1910.

**Astra-Torres.** In reviewing the specifications of any of the big dirigibles, the observer cannot fail to be struck by the excessive amount of power necessary to drive them at speeds which are lower than the minimum, or landing speeds, of many aeroplanes. When a speed of 45 miles per hour was first reached by a dirigible, it was acclaimed as a great feat. But this comparatively moderate rate of travel was surpassed only by increasing the number of motors and their horsepower until the fuel consumption became exceedingly high. This necessitated the carrying of a great weight of fuel and cut down correspondingly the useful load that the dirigible was capable of lifting as well as restricted its radius of flight at full speed. Until aerodynamic research had demonstrated the contrary, the necessity for such a tremendous amount of power was considered necessary to overcome the head resistance of the balloon itself. Research brought out in a striking manner how great a proportion of the total head resistance of an aeroplane was due to the struts and bracing wires. In the construction of the different types of airships illustrated, it will be noted that the gear provided for suspending the car or cars below the balloon requires a great number of cables. Later developments showed that by eliminating the great amount of head resistance caused by these numerous surfaces, the speed of a dirigible could be increased by over 50 per cent with the same amount of power.

[image]

*Fig. 14. Section of Astra-Torres, Illustrating Method of Suspension. CB, Bracing of Heavy Fabric Bands; SR and A, Suspension Ropes and Cable Passing through Envelope; S, Expansion Sleeve in Envelope; CC', Ropes to Sides of Car; E, Envelope*

*Improved Suspension.* The shortcoming of the dirigible with reference to suspension was realized more than ten years previous by a Spaniard—Torres—but owing to lack of financial support, he was unable to put his idea into execution. The principle he evolved is made clear by Fig. 14, which gives a section of an Astra-Torres dirigible illustrating the method of suspension. Instead of the ropes *SR* used to suspend the car being attached to bands passing around the envelope, these reinforcing bands *CB* and also the ropes fastened to them are placed inside the envelope, thus eliminating head resistance from those sources.

*Performance.* Failing to obtain any encouragement in Spain, Torres finally succeeded in interesting the French Astra Company, which built a vedette, or scouting airship, of a little over 50,000 cubic feet capacity. It was pitted against the Colonel Renard, at that time the leading unit in the French aerial navy and the fastest airship in commission. The small Torres dirigible so completely outclassed its huge competitor that another of close to 300,000 cubic feet capacity was built and tried against the Parseval with similar results. An Astra-Torres dirigible built for the British government showed a speed in excess of 50 miles per hour. This particular dirigible has been at the front in France almost since the outbreak of hostilities and has rendered considerable valuable service. Its success led the French Government to order a huge replica of it, having a capacity of over 800,000 cubic feet and with motors developing 1,000 horsepower, which would give it an indicated speed of 60 miles per hour. So confident were its builders of attaining or even exceeding this, that an order for a second and even larger airship of the Astra-Torres design was placed before the first one was finished. This is also fitted with motors aggregating 1,000 horsepower and displaces 38 tons, making it larger than any Zeppelin that had been constructed up to the time it was built. As its construction and trials were undertaken during the war, no details have been published, but it is said on good authority that its speed exceeds 60 miles per hour, so that it is faster than any of the German dirigibles.

*Construction.* Unlike the German dirigibles, the larger types of which have been characterized by a rigid frame, the Astra-Torres is a flexible airship and, owing to its method of suspension, its external appearance is decidedly unconventional, since the envelope instead of being of the usual cigar shape is more like a triangular bundle of three cigars with the third one on top. At the point where the three envelopes join, as shown in section, Fig. 14, heavy cloth bands *CB* are stretched across the arcs, forming a chord across each arc, the three chords comprising an inverted triangle. The suspension ropes *SR* are attached to the opposite ends of the base of this inverted triangle and converge in straight lines downward through the gas space, so that the air resistance offered by the ropes is practically eliminated since only a very small part of the suspension system appears outside the envelope. This external part consists of vertical cables *A* at-

tached to the collecting rings of the bracing system and extending downward through special accordion sleeves *S* which permit the free play necessary at the points where they pass through the outer wall of the envelope. These sleeves also have another function—that of permitting the escape of gas under the pressure of expansion. A short distance below the envelope *E* each of these cables splits into two parts *C* and *C'* attached to opposite sides of the car.

The British airship mentioned is provided with but one car, but the larger French ships have two placed tandem, each of which carries a 500-horsepower motor driving two two-bladed propellers of large diameter. While the form of envelope made necessary by this construction increases the frictional resistance, this is negligible in comparison with the great saving in power effected by the method of suspension, not to mention the greater simplicity of construction.

## GERMAN DIRIGIBLES

**Early Zeppelin Airships.** At the same time that Santos-Dumont was carrying on his hazardous experiments, the problem was being attacked along slightly different lines by Count Zeppelin.

It will be remembered that Dumont experienced much trouble on account of the envelope of his balloon being too flexible, causing it to crumple in the middle and to become distorted in shape from the pressure of the air. His efforts to overcome this by the employment of air bags did not meet with great success, even in his later types.

[image]

*Fig. 15. Zeppelin Dirigible Rising from Lake Constance*

*Construction.* Zeppelin employed a very rigid construction. His first balloon, which was built in 1898, was the largest which had ever been made. It is illustrated in Fig. 15, which shows his first design slightly improved. It was about 40 feet in diameter and 420 feet long—an air craft as large as many an ocean vessel. The envelope consisted of two distinct bags, an outer and an inner one, with an air space between. The air space between the inner and outer envelopes acted as a heat insulator and prevented the gas within from being affected by rapid changes of temperature. The inner bag contained the gas, and the outer one served as a protective covering. In the construction of this outer bag lies the novelty of Zeppelin's design. A rigid framework of strongly braced aluminum rings was provided and this was covered with linen and silk which had been

specially treated to prevent leakage of gas. The inner envelope consisted of seventeen gas-tight compartments which could be filled or emptied separately. In the event of the puncture of one of them, the balloon would remain afloat. An aluminum keel was provided to further increase the rigidity. A sliding weight could be moved backward or forward along the keel and cause the nose of the airship to point upward or downward as desired. This would make the craft move upward or downward without throwing out ballast or losing gas. Lender each end of the balloon a light aluminum car was rigidly fastened and in each was a 16-horsepower Daimler gasoline engine. The two engines could be worked either independently of each other or together. Each engine drove a vertical and horizontal propeller. The propellers each had four aluminum blades. As will be seen from Fig. 15, the ears were too far apart for ordinary means of communication and so speaking tubes, electric bells, and an electric telegraph system were installed.

*First Trials.* Very little was known as to the effects of alighting on the ground with such a rigid affair as this vessel, therefore the cars were made like boats so that the airship could alight and float on the water. The first trials were made over Lake Constance in July, 1900. The mammoth craft was housed in a huge floating shed, and the vessel emerged from it with the gas bag floating above and the two cars touching the water. She rose easily from the water, and then began a series of mishaps such as usually fall to the lot of experimenters. The upper cross stay proved too weak for the long body of the balloon and bent upward about 10 inches during the flight. This prevented the propeller shafts from working properly. Then the winch which worked the sliding weight was broken and, finally, the steering ropes to the rudders became entangled. In spite of all this, a speed of 13 feet per second, or about 9 miles per hour, was obtained. These breakages made it necessary to descend to the lake for repairs and in alighting the framework was further damaged by running into a pile in the lake. The airship was repaired and another flight was made later in the year, during which a speed of 30 feet per second, or 20 miles per hour, was obtained.

*Second Airship.* Zeppelin had sunk his own private fortune and that of his supporters in his first venture, and it was not till five years later that he succeeded in raising enough money to construct a second airship. No radical changes in construction were made in the new model, but there were slight improvements made in all its details. The balloon was about 8 feet shorter than the original and the propellers were enlarged. Three vertical rudders were placed in front and three behind the balloon, and below the end of the craft horizontal rudders were installed to assist in steering upward or downward. The steering was taken care of from the front car.

The most important change was made possible by the improvement in

gasoline engines during the preceding five years. Where, in the earlier model, he had two 16-horsepower engines, he now used an 85-horsepower engine in each car, with practically the same weight. In fact, the total weight of the vessel was only 9 tons, while his first airship weighed 10 tons.

His new craft made many successful flights. One was made at the rate of 38 miles per hour and continued for seven hours, covering a total distance of 266 miles.

**Later Zeppelins.** The later Zeppelins embody no remarkable changes in design, the principal alteration being in size. One of these is illustrated in Fig. 16. In this the gas bag was increased to 446 feet in length and it held over 460,000 cubic feet of gas. This gave it a total lifting power of 16 tons. With this, Zeppelin made a voyage of over 375 miles. He was in the air for twenty hours on this trip and carried eleven passengers with him.

[image]

*Fig. 16. Zeppelin Airship in Flight*

In August, 1908, the Zeppelin left its great iron house at Friedrichshafen and sailed in a great circle over Lake Constance. The day after it started, however, it was destroyed by a storm, and sudden destruction from one cause or another has ended the existence of practically every one of the Zeppelins built since, usually after a very brief period of service.

**Shape and Framing.** In the early days of dirigible design the data upon which the shape and proportions of the envelope were based were purely empirical. Schwartz, Germany's pioneer in this field, adopted the projectile as representing the form offering the least air resistance and accordingly designed his envelope with a sharply pointed bow and a rounded-off stern, giving it a length four times its diameter. Zeppelin did not agree with these conclusions and adopted a pencil form, rounded at the nose and tapering to a sharp point at the stern, making the length nine to ten times the diameter. Subsequent research work in the aerodynamic laboratory has demonstrated that the most efficient form for air penetration is one having a length six times its maximum diameter with the latter situated at a point four-tenths of the total length from the bow. It has likewise been proved that an ellipse is more efficient than either the projectile or pencil form and that tapering to a sharp point at the stern offers no particular advantage. As a result, the most approved form resembles the shape of a perfecto cigar, the nose being somewhat blunter than the after end. This form is likewise that of the swiftest-swimming fishes and has been shown to have the least head



resistance as well as the minimum skin friction; it results in a section to which the term *stream-line* has been applied, and it is now employed on all exposed non-supporting surfaces on aeroplanes, such as the struts and even the bracing cables. Laboratory research has demonstrated that it is worth while to reduce the head resistance of even such apparently negligible surfaces as those presented by these wires and cables and, therefore, they are stream-lined by attaching recessed triangular strips of wood to their forward sides.

*Framing Details.* Despite this, the builders of the Zeppelins have adhered to the original pencil shape with but slight modifications at the bow and stern, probably because that shape is much easier to build and assemble from standard girders. The form of girder employed is shown in Fig. 17, while the complete assembly of the frame is illustrated in Fig. 18. The girders form the longerons, or longitudinal beams, running the entire length of the rigid frame and supported at equidistant points by ring members built of similar girder sections. The fourth ring from the nose and each alternate ring after that are further braced by being trussed to the longitudinal beams around their entire circumferences, as shown in Fig. 18. The larger V-shaped truss at the bottom forms the gangway, which is now placed inside the envelope instead of being suspended beneath it, as formerly. This is done to eliminate the head resistance set up by the additional surface thus exposed. In the first instance in which this gangway was incorporated in the envelope, no provision was made for ventilation, and the ship was wrecked by a gas explosion. Regardless of how tight the fabric is made, gas is always oozing out through it to a greater or less extent. This fact is now met by providing ventilating shafts leading from the gangway to the upper surface of the envelope. Additional shafts through the envelope lead to gun platforms, forward, amidships, and aft, and are reached by aluminum ladders.

[image]

*Fig. 17. Trellis Type of Aluminum Girder used in Longitudinals of Zeppelin Frame*

[image]

*Fig. 18. Aluminum Frame Construction of Zeppelin Hull*

*Framing of Schutte-Lanz Type.* It has become customary to refer to all large German airships as Zeppelins, but many of those used during the past three years

have been of the Schutte-Lanz build, which is also a rigid frame type of dirigible but has been designed with a view of overcoming some of the disadvantages of the aluminum frame construction encountered in the use of the Zeppelin. The length and diameter of the latter airships are such that, no matter how rigidly the framing is assembled, there is more or less sag. When the sag exceeds a certain amount, the frame is apt to buckle at the point where it occurs, involving expensive repairs or wrecking the airship altogether. To overcome this difficulty, the Schutte-Lanz type employs a rigid frame of flexible material, namely, laminated wood in strip form, held together at joints and crossings by aluminum fittings and braced inside by cables. As shown by Fig. 19, no rigid longitudinal beams are employed, the only girders used being rings, to which a network built of the wood strips is attached. Starting at the nose, each continuous strip follows an open spiral path such as would be traced in the air by a screw of very large pitch, in fact, approximating the rifling of a gun barrel. It will also be noted from the illustration that the form of the Schutte-Lanz airship is the cigar-shape, which laboratory research has shown to be the most efficient.

[image]

*Fig. 19. Schutte-Lanz Type of Frame Construction of Laminated Wood with Aluminum Fittings*

The use of wood in conjunction with the spiral construction of the supporting members of the framing affords the maximum degree of flexibility, since the displacement of any of these members under stresses of either tension or compression would have to be very great to cause damage to the frame as a whole. The frame not being rigid, strictly speaking, either as units or as a complete assembly, stress at any particular point would simply cause all the members near that point to give in the direction of the strain, and the rest of the frame would accommodate itself to their change of position by either elongating or shortening slightly. In addition to these advantages, the Schutte-Lanz type of construction is said to be lighter than the Zeppelin for an airship of the same load-carrying capacity.

**Power Plant.** Compared with their successors of war times, the early Zeppelins were mere pigmies where power is concerned. Many of these pioneers were driven by less than 100 horsepower all told, whereas in the later types no single motor unit as small as this total has been employed. The motors used most largely have been the 160-horsepower Mercedes and the 200-horsepower Maybach, both of which are described in detail under the title "Aviation Motors."

From five to ten of these units have been used on a single ship, giving an aggregate in some of the latest types of close to 2,000 horsepower. Power has been applied through five or six propellers to limit their diameter and to guard against the breakdown of any one of the units putting the power plant out of commission as a whole. To distribute the weight of the engines equally and to insure each propeller a position in which it can work in undisturbed air, the engines have been placed at widely separated points on the airship and in different planes so that no two are coaxial. The main engine room is usually located in a cabin just back of the operating bridge and wireless room, while the remaining motors are suspended in independent gondolas at different points along the sides. Where more than 1,000 horsepower has been used, each of these gondolas' has been fitted with two motors placed side by side and so coupled that either one or both may be employed to drive the single propeller carried by the propelling car. All the more recent propellers have been of the two-bladed type.

**Control Surfaces.** The numerous expedients formerly resorted to by various designers in providing for stabilizing, steering, and elevating surfaces have been abandoned for forms that are practically a duplication of aeroplane practice. Experience demonstrated that the different types of multiplane rudders, elevators, and stabilizing surfaces employed in earlier days not only offered no operating advantages but were actually detrimental, in that they increased the head resistance unnecessarily. Moreover, their complication meant increased weight and weaker construction. They have accordingly been displaced by monoplane surfaces which are of exactly the same type of construction as those used on the aeroplane and the location and proportions of which are very evidently based on aeroplane practice. Both the horizontal and vertical stabilizers are of approximately triangular form and have the steering and elevating surfaces hinged to them at their after ends, so that, except for the pointed extremity of the envelope which extends beyond them, the tail unit of the later Zeppelins is practically the same as the empennage of an aeroplane. The horizontal surfaces are apparently depended on entirely to effect the ascent and descent, there being no evidence of swiveling propellers by means of which the power of the engines could be employed to draw the airship up or down. The great weight of ballast carried is, of course, in the form of water, but this is discarded in order to ascend only when the power of the engines exerted against the elevating planes is no longer capable of keeping the airship at the altitude desired. In the low temperatures encountered in night flights, however, the contraction of the hydrogen gas is so great that the crew has found it necessary to reduce the weight by discarding not only every pound of ballast but, as far as possible, everything portable. Despite this, several airships have fallen when their fuel supply was exhausted, one coming to the ground in Scotland, two dropping into the North Sea, and three or four

falling in France.

**Operating Controls.** All the operating controls are centered at the navigating bridge, which is inclosed to form the commander's cabin. By means of push buttons, switches, levers, and wheels every operating function required is set into motion from this central point. Whether auxiliary motors are carried for the purpose of pumping air into the balloonets or this is one of the duties of the main engine just back of the wireless room does not appear, but with the aid of a push button board the amount of air in any of the balloonets may be increased or decreased at will. There is a control button for each operation, or two for each balloonet, which fact necessitates a rather forbidding looking board, since the more recent Zeppelins have seventeen to nineteen gas bags within each of which is incorporated an air balloonet.

The amount of fuel supplied to any one of the motor units can likewise be controlled from a central board, and this is also true of the ballast release apparatus, so that water can be emptied from any one of the ballast tanks at will, thus facilitating ascent or descent by lightening one end or the other. Elevating and steering surfaces are operated by small hand-steering wheels with cables passing around their drums, a member of the crew being stationed at each of these controlling wheels. Owing to the number of motors used, the instrument board is the most formidable appearing piece of apparatus on the bridge, since there is a revolution counter for each power unit in addition to the numerous other instruments required. Some of these instruments are the aneroid barometer for indicating the altitude, transverse and longitudinal clinometers to show the amount of heel and the angle at which the airship is traveling with relation to the horizontal, the anemometer, or air-speed indicator, manometers, or pressure gauges, for each one of the gas bags, fuel and ballast supply gauges, drift indicators, electric bomb releasers, mileage recorders, and the like. In addition to these, there are a large chart and a compass, so the navigating bridge of a Zeppelin combines in small space all the instruments to be found in the engine room and on the bridge of an ocean liner besides several which the latter does not require. That the proper co-ordination of all the functions mentioned is an exceedingly difficult task for one man seems evident from the numerous Zeppelins that have apparently wrecked themselves.

**Crew Carried.** In the various Zeppelins that have been captured or shot down by the British or French, the personnel has varied from fifteen to thirty men but in the majority of instances has not exceeded twenty. The positions and duties are about as follows: The commander, lieutenant-commander, and chief engineer, and possibly a navigating officer are stationed at the bridge. Two or three of the crew are also stationed there to work the manually operated controls. In the cabin just back of the bridge are two wireless operators and one or two

engine attendants for the motors in the engine room behind the wireless room. A similar number of engine attendants are stationed in the after engine room and there is at least one attendant for each of the other motor units. One man is stationed at each machine gun, of which there are three to five on the "roof" and two in each car, and at least as many bombers are needed to load the "droppers." As a reserve there are usually an additional gun pointer for each gun and an extra engine attendant, since to run continuously most of the crew would have to stand watch and watch as in marine practice. The sleeping accommodations consist of canvas hammocks slung in the gangway.

**Explosives Carried.** In addition to a liberal supply of ammunition for the machine guns, a large weight of bombs is carried, though the quantity as well as the size of the bombs themselves has been exaggerated in the same or even greater ratio than that which has proved characteristic of the German military press-agency service. The bombs are carried suspended in racks amidships, and the bomb droppers are also located at that part of the ship so that the release of the bombs will not upset the longitudinal equilibrium of the craft. The bomb-dropping apparatus is controlled electrically from the navigating bridge but may also be operated by hand from the same point. It has been reported by the Germans that their latest types of Zeppelins are capable of dropping bombs weighing 1 ton each. In view of the effect that the sudden release of a weight of 1 ton would have on the airship itself, this is manifestly very much of an exaggeration. Zeppelin bombs that have failed to explode have never exceeded 200 to 300 pounds and many of those employed are doubtless still lighter. So far as the total amount carried is concerned, many of the later airships doubtless are capable of transporting 2 to 3 tons and still carrying sufficient fuel, though adverse conditions would prevent their return, as has frequently happened.

## BRITISH WAR DIRIGIBLES

**Adoption of Small Type.** German designers have continued to pin their faith blindly to the huge rigid type, despite the fact that prior to the war almost a dozen of these costly machines met with disaster as fast as they could be turned out. Since the war started, their destruction has kept pace pretty closely with their building without their accomplishing anything of military value. The British naval aeronautic service, on the other hand, appreciated the futility of such tremendous and unwieldy construction and, after a single demonstration of its uselessness, abandoned it altogether. This single attempt was the ill-fated *Mayfly*, which was most appropriately named, since its performance resolved into a certainty the doubt expressed by its title. In being taken out of its shed,

the framing of the airship was damaged, and it collapsed a few minutes later so that it never did fly. One of the early types of small British dirigibles is shown in Fig. 20.

Attention has since been concentrated in most part on the construction of aeroplanes in constantly increasing numbers, although the dirigible has not been given up altogether. However, its restricted usefulness as well as the necessary limitations of its effective size has been recognized. Early in the war Great Britain planned the construction of fifty small dirigibles, of both the rigid and nonrigid types, all of which have undoubtedly since been completed. They are small airships designed chiefly for scouting and short-range bombing raids over camps when in army service and for coast patrol and submarine hunting as an aid to the naval forces. While no specifications are available, the cubic capacity of these patrol airships probably does not exceed 50,000 to 75,000 cubic feet, their over-all length being approximately 100 to 125 feet.

[image]

*Fig. 20. An Early Type of Small British Dirigible*

**Aeroplane Features.** To simplify the construction and at the same time minimize the amount of head resistance, the car consists of an aeroplane fuselage of the tractor type, fitted with a comparatively small motor—under 100 horsepower—and having accommodations for a pilot and an observer in two cockpits, placed tandem. The control surfaces are also similar to those used in aeroplane construction. Despite their low power, these dirigibles can make 40 miles an hour, owing to their greatly reduced head resistance. Instead of employing either an auxiliary blowing motor or a blower driven by the motor itself, the supply duct to the air balloonet is made rigid and is sloped forward so that its open end comes directly in the slip stream of the propeller; thus the latter serves to inflate the balloonet as well as to drive the dirigible. The desired amount of inflation is controlled by a valve.

[image]

*Fig. 21. Side and End Views of British Astra-Torres Dirigible Used for Anti-Submarine Patrol Service*

**Use in Locating Submarines.** Many of these small scouting and naval-patrol dirigibles have given a good account of themselves and comparatively few have

met with accident or have been destroyed by the enemy. On frequent occasions they have been very successful in locating submarines below the surface, since the body of the under-water boat is readily detected from an altitude of a thousand feet or more, even though submerged to a great depth and despite a heavy ripple on the surface that makes the water absolutely opaque when viewed from the deck of a ship. Doubtless they will be employed to an increasing extent as the hunt for the submarine becomes more and more intensive, though their use is very much restricted during the winter months, owing to the frequent and severe storms encountered.

**British Astra-Torres.** A number of comparatively small Astra-Torres dirigibles have also been built in Great Britain for coast patrol and anti-submarine work. The line drawing at the left of Fig. 21 illustrates the general design and construction of these small airships, while the various letters indicate the different parts of the gas container, air balloonets, suspension and car, and the end view at the right of the figure shows the small amount of head resistance offered by the suspension of this type as compared with that of the usual form of nonrigid dirigible. *A* is the balloon itself, or main gas container, the pressure relief valve for which is located at *M*. *BB* are the air balloonets connected with the blower *H* in the car. In the illustration these balloonets are shown fully inflated as they would be after the gas bag had lost a considerable proportion of its original contents through leakage or expansion. At the beginning of a flight, when the gas bag is fully inflated with hydrogen, they lie perfectly flat along the lower side of the envelope, being brought into service only as they are needed to keep the envelope distended to its full volume.

The novel method of suspension to which this type of dirigible owes its greater speed and fuel economy, because of the reduction of the head resistance, is shown by the numerous supporting ropes *O-O-O*, which terminate in a comparatively few cables attached to the car. In the small British airships referred to here, there is but one small car designed to carry a crew of two men and the engine is of comparatively low power, driving a propeller at either end of the car, but in the large French dirigibles of the same type, two large cars are placed tandem some distance apart and are fitted with 500-horsepower motors. The various parts indicated by the letters are: *CC* propellers, *D* motor, *F* space for pilot and crew, *G* fuel and oil tanks, *J* guide rope, *K* gas valve, *LL* air valves, *NN* balloonet cable, *P* rudder, *Q* stabilizer, *RR* bracing cables, and *S* the car itself.

## MILITARY USES OF ZEPPELINS

**Limitations of Use.** Nothing excites the Teutonic imagination so strongly as

things military to which the characteristic German adjective *kolossal* can be enthusiastically applied. It was for this reason that, despite its uniform record of tragic disaster for years before the war, the Germans pinned their faith to the Zeppelin as a weapon that could not fail to strike terror to the hearts of the British and French and make them hasten "to sue for peace." However, apart from its reputed employment on the single occasion that the German grand fleet left the security of the Kiel Canal, it is not known to have been used in any purely military operation. The aeroplane has been developed to a point that, in spite of the ability of the Zeppelin to ascend rapidly when hard pressed, would make it suicidal for one of the huge gas bags to sally forth in daylight, unless attended by a large number of battle planes to prevent enemy flying machines from attacking it. No such use of the Zeppelin has been recorded thus far. Consequently, it has been used only in nocturnal bomb-dropping expeditions, chiefly directed against London and only undertaken when weather conditions made detection difficult. In order to carry these out, it has been necessary to establish stations in Belgium, since the fuel consumption of the Zeppelin is so great that, even with its tremendous fuel supply of 3 to 5 tons, a flight to London and return to points well within the German border is impracticable. The first raids of this character were carried out successfully, but subsequent attempts were marked by the loss of one or two airships on each occasion, so that the practice was abandoned as being too expensive for the results attained and aeroplanes were substituted.

**Number Built.** Taking it for granted that the numbering of the German airships has been consecutive, the total number built during the first three and one-half years of the war by the Germans would be between eighty and one hundred. All large German airships have come to be commonly termed Zeppelins, but a number of them were of the Schutte-Lanz type, almost equally large and also characterized by rigid construction, which, however, was of wood with aluminum fittings instead of being all metal, as it was found that the huge metal frame accumulated a static charge of high potential that was responsible for igniting the gas in one or two instances.

**Weakness of Type.** The L-I (*Luftschiff*, or airship), the first of the German airships designed for purely military purposes, was a Zeppelin 525 feet long by 50 feet in diameter, of 777,000 cubic feet capacity, and 22 tons displacement. Its three sets of motors developed 500 horsepower and it had a speed of 52 miles per hour. It was launched at Friedrichshafen in 1912, and after a number of successful cross-country trips, it was tried in connection with naval maneuvers off Heligoland. Before the trial had proceeded very far, a sudden squall broke the backbone of the huge gas bag and hurled it into the sea, drowning fifteen out of the crew of twenty-two. It is a striking commentary on the frailness of these aerial monsters that every one of the big airships built up to that time had met



disaster in an equally sudden manner but from a totally different cause in each instance. The L-II was slightly shorter but had 5 feet longer beam and displaced 27 tons. She was designed particularly for naval use, had four sets of motors developing 900 horsepower, and was fitted with a navigating bridge like that of a ship. It was confidently thought that all possible shortcomings had been remedied and success finally achieved in the L-II, but before there was any opportunity to demonstrate its efficiency, the airship exploded in mid-air, killing its entire crew.

*Effectiveness Grossly Overrated.* Despite this unbroken chain of disasters, the German official press bureau spread broadcast the prowess of the Zeppelin, its magnificent ability, and its remarkable achievements as an engine of war—in theory, since this was a year or two prior to the outbreak of hostilities. Had it not been for the forced descent of the Zeppelin IV at Luneville, where it was taken possession of by the French, these tales might have been accepted at their face value. But the log of the commander of this airship showed that its maximum speed was but 45 miles per hour, the load 10,560 pounds, and the ascensional effort 45,100 pounds. The fuel consumption averaged 297 pounds per hour while the fuel capacity was only sufficient for a flight of seven hours. During its flight, it had reached an altitude of only 6,250 feet, to accomplish which over 3 tons of ballast had to be dropped. It was also shown that the critical flying height of these huge airships is between 3,500 and 4,000 feet, Zeppelin himself declaring that his machines were useless above 5,000 feet. This probably accounts for the fact that the early raids on English towns were carried out at a height but slightly in excess of 2,000 feet. Later types, however, are said to have reached high altitudes.

[image]

*Fig. 22. Zeppelin L-49 Brought Down Intact by a French Airman,  
Resting on Hillside near Bourbon-Les-Baines  
Copyright by Underwood and Underwood, New York*

Shortly before the outbreak of the war the L-5 was completed. This had a capacity of about 1,000,000 cubic feet, motors aggregating 1,000 horsepower or over, and a reputed speed of 65 miles per hour. Just what was the fate of this particular ship did not become known, since information of a military character has not been permitted to leak out of Germany from that time on. But capture or destruction has accounted for many of the intermediate numbers of the series; big German airships have been brought down in England, in the North Sea, in France, and at Saloniki, their loss culminating in the disaster to four out of the fleet of

five that attempted a raid over London but were caught by adverse winds which exhausted their fuel supply so that they were blown out of control, toward the south of France. French anti-aircraft batteries or aeroplanes accounted for three of these, while the fourth, the L-49, was captured intact.

[image]

*Fig. 23. Nose of Giant L-49 and Group of Sightseers  
Copyright by Underwood and Underwood, New York*

L-49. An essential part of the equipment of every form of German military apparatus is a means of destroying it in case of capture. In the case of the big airships, the officers are provided with revolvers loaded with incendiary bullets, which are fired into the gas bag, so that until the L-49 was forced to descend in the south of France by the activities of a battle plane, plus a lack of fuel, no airship of a recent type had ever been captured intact. In this case, the commander fired his pistol at the balloon but missed and was prevented from firing again by a French peasant who "covered" him with a shotgun. The wireless operator succeeded in using a sledge hammer on some of the apparatus of the very completely equipped wireless cabin before he was captured but did not do sufficient damage to prevent reassembly of the parts with little trouble. With the exception of the earlier type of Zeppelin that was forced to descend at Luneville prior to the war, the L-49 was the first that was ever known to have landed undamaged in hostile territory, as practically all the others were destroyed in the air, most of them having been wrecked either by aeroplane or anti-aircraft fire. Fig. 22 shows the L-49 as it rested on a hillside at Bourbon-les-Baines, France, and Fig. 23 shows a close view of the nose of the monster.

*Standardized Parts.* Comparing the L-49 with many of its predecessors led to the conclusion that it was one of the latest types, but an inspection of its construction revealed the use of many parts produced in quantities from standard patterns as well as a lack of the finish that has always characterized airship construction. Appearance and comfort had both been sacrificed with a view to saving the last ounce of superfluous weight in order to carry more fuel and ammunition. Evidently the production of these large airships has been reduced to a manufacturing basis and they are constructed in series in much the same manner as motor cars, though on a reduced scale.

*General Design.* In its general construction the L-49 was along the same lines that have characterized the Zeppelin since its inception, the outer envelope being stretched over a rigid frame of aluminum girders, inclosing a large number

of independent balloons inflated with the usual hydrogen gas, no trace being discovered of the non-inflammable gas, the discovery of which had been hailed by the German press. The commander's cabin was suspended well forward with the wireless room directly behind it, while a V-shaped gangway, recessed in the envelope proper so as to present no additional head resistance, ran back from the latter the whole length of the ship. This and the gun platform on top, mounting two machine guns and reached by a ladder suspended in a well amidships, have been familiar features of all the recent Zeppelins. The main envelope contained nineteen independent gas bags, each of which was made integral with an air balloonet to take care of the expansion and contraction of the hydrogen with varying altitudes and temperatures. Distributed along the lower part of the frame inside the envelope were a series of 50-gallon water-ballast tanks.

*Power Plant.* No less than nine large motors were employed to drive the huge gas bag, the maximum horsepower probably aggregating 1,600 to 2,000. The motors were distributed in five different locations, the largest being suspended just abaft the wireless room. The remainder were placed in self-contained units in the form of gondolas suspended from the sides of the frame, as shown in Fig. 24, the outline being that of a blunt-nosed fish. Each of these gondolas carried two motors placed side by side and coupled up so that either one or both could be employed to drive the single propeller. For cruising speeds one motor in each gondola supplied sufficient power or in some gondolas both motors could remain idle. No accommodation was provided for attendants in the gondolas, any of which could easily be reached by light ladders from the inclosed gangway.

To insure greater safety, the fuel supply was divided among sixteen tanks, all of which were interconnected with each other and the engines so that gasoline from any tank or tanks could be diverted to any particular engine. The supply of lubricating oil for each engine was carried in a tank in the gondola itself.

*Control.* Vertical and horizontal stabilizing surfaces of conventional form were built on the sharply tapering rear end of the frame, the elevator and rudder being similar to those used in aeroplane construction, except that the rudder was in two sections, the larger of which was placed on top of the envelope. The control of these surfaces, the operation of all the engines, the control of the water ballast, the air supply to the balloonets, and the fuel supply to the motors were all concentrated at a panel board in the commander's cabin, the forward end of which bore a close resemblance to the bridge of a man-of-war. By means of thirty-eight push buttons, half red and half white, air could be released from or pumped into the balloonets, while in a similar manner the contents of any one of the water-ballast tanks could be emptied. Elaborate controls were provided for the power plant, it being possible to vary the speed or stop any one or more of the motors from the bridge. The rudder and elevators were operated by means of

small hand wheels, similar to a marine steering wheel. One of the most prominent features of the operating cabin was a huge chart frame, capable of carrying a large scale map covering a considerable area, as well as an ample supply of maps. Few instruments were found in the captured ship and it is thought highly probable that everything not fastened in place had been dumped overboard at the last to increase its lifting power.

[image]

*Fig. 24. One of Six Gondolas, or Power Units of the Zeppelin L-49  
Copyright by Underwood and Underwood, New York*

Apart from the use of standardized fittings and parts and the employment of a great deal more power in a slightly different manner than had characterized the earlier types of Zeppelins, the L-49 revealed nothing of unusual importance in airship design and certainly none of the world-beating features that German propaganda had been heralding for some time previous.

**Destruction of Zeppelins.** Mention has already been made of the fact that practically the only use made by Germany of her huge airships has been the bombardment of open cities, and that always at night. From the first of September, 1914, up to the end of 1917, between thirty and forty had met disaster, but only two were captured intact. The first of these was discovered by a Russian cavalry patrol while at anchor and its crew of thirty men were made prisoners. This was at an early period in the war, while the second one to be captured was the L-49, already referred to, which formed one of a squadron of five evidently sent out on a bombing expedition against London. Owing to adverse winds, they never reached their destination and four of them were known to have been put out of action, all except the L-49 being destroyed in the air. Not a few of these big airships have fallen victims to their own weakness and succumbed to the elements, in one instance a high wind tearing the airship loose from its moorings while the crew was not aboard. This was at Kiel, and after traveling a number of miles unguided, the big bag fell into the North Sea. In quite a number of other cases head winds have prevented the return of the raiders to their base and they have either been destroyed by their crews or wrecked at sea in attempting to return. In still other instances the unwieldy monsters have been wrecked by high winds when attempting to land, as was so frequently the case prior to the war.

*Aeroplane and Anti-Aircraft Fire Effective.* Before the war broke out the ability of either the aeroplane or the anti-aircraft gun to overcome the Zeppelin was purely theoretical, but actual experience has demonstrated that much of the

theory was well founded. At least three Zeppelins have been destroyed by British aviators in mid-air, all or most of the crews being killed, while probably an equal number have been accounted for by French aviators in open battle. The war had not been under way a month before French anti-aircraft gunners showed their skill by bringing down-a "Zep," while only a week later a Russian battery accomplished the same feat, in this instance killing the entire crew. In 1916, British and French gunners succeeded in either "winging" or setting on fire three or four, while two dropped into the North Sea and one was blown up by its crew, having run out of fuel while raiding Scotch towns.

*Bombing Raids against Zeppelin Sheds.* Not the least of the disadvantages from which such huge and unwieldy craft suffer is the fact that the correspondingly large structures required to house them make exceedingly easy marks for the raiding aviator. Bombing, however, is such an uncertain art that even such large buildings as these cannot be struck from any altitude with a fair degree of accuracy. Consequently, in the number of raids that have been carried out against Zeppelin sheds, success has been due very largely to the temerity of the aviators, who have descended within a few hundred feet of their mark despite the fire directed at them from all quarters. At least three and probably more of the big airships have been destroyed in this manner by British aviators, who have made flights of several hundred miles to reach their destination, while the destruction of as many more has been ascribed by the Germans to the "accidental" explosion of a bomb in the shed. In view of the great precautions taken against accident from the explosion of the bombs carried by the airship itself, it is not considered at all likely that there was anything accidental about the wrecking of these craft.

One of the earliest attempts against Zeppelin headquarters at Friedrichshafen on Lake Constance, which resulted in the destruction of the L-31, is typical of the plan followed in attacks of this kind. Two British aviators flew from their base in France, about 250 miles distant, at a high altitude. They became separated before reaching their destination owing to a mist. This, however, prevented their discovery until they had dropped within a few hundred feet of the surface of the lake, which it was necessary to do to obtain a view of the airship sheds. The first pilot dropped his cargo of bombs from a height of only 100 feet or so over the shed and was rewarded by seeing it catch fire. He had hardly straightened out on his return course before he heard the attack of his companion. The latter was not so fortunate in escaping unscathed, as a bullet pierced his fuel tank and compelled him to descend. In the majority of instances, however, the raiders have succeeded not only in carrying out their task but in escaping undamaged as well.

## CAPTIVE BALLOONS

**Military Value.** As an aid to military operations, the use of the captive balloon dates back many years. It was extensively employed in the Civil war and more recently in the Boer war, but with the advent of both the dirigible and the aeroplane, it was generally considered outside of Germany that its reason for existence had passed away. The German military plans included a large number of balloons for artillery observation purposes and they were used right from the start. It was only when the fighting settled down to trench warfare, however, that they came into prominence and the aid that they rendered the German batteries put their opponents at a serious disadvantage. Like the bayonet, which was also generally considered to have been relegated to military operations of the past, the captive balloon is now playing a very important role, particularly on the western front. In favorable weather, anywhere from ten to forty of these aerial observation posts will be visible from a single point on the line.

**Spherical Type Defective.** The captive balloon of the present day, however, bears no resemblance to its predecessors. From a sphere, it has been developed into a form that more nearly resembles the dirigible and at the same time, it embodies some of the features of the aeroplane. The old spherical balloon was always at the mercy of the wind, which not only governed the altitude to which the balloon would rise but also made things extremely uncomfortable as well as dangerous for the observers. With 1,000 feet of cable out, such a balloon rises to an equivalent height on a perfectly, calm day. But even a light wind cuts this height down by 100 or 200 feet, while if a strong wind is blowing, the balloon is held down to within a few hundred feet of the ground regardless of the length of cable paid out. Every strong gust beats it over at a perilous angle and the resulting shocks to the basket are so severe that its occupants can have little thought for anything but their own safety. Strong cross gusts set both the bag and basket to spinning and jumping in a manner that would make the results of the severest storm at sea seem mild by comparison, since the movements of the basket are executed with such rapidity that they seem to be in almost every plane simultaneously. As a result, the old type of captive balloon was available for service only in the calmest weather.

**Modern Kite Balloon.** It should not be supposed that the improved type of observation balloon now in use in such large numbers provides any unusual amount of ease or comfort, since it is also prey to the wind and does a great deal of swinging about as well as jerking when the wind is more than 15 or 20 miles an hour. But it has been improved to a point where the wind not only serves to elevate, instead of depressing it, but also to steady it. The new type. Fig. 25, is technically known as a kite balloon, because, in addition to the appendages

attached to the bag itself for steadying purposes, it is equipped with a tail to assist in keeping it heading into the wind. This consists of a number of bucket-shaped pieces of heavy canvas attached to the tail cable by bridles so as to catch the wind and hold it, thus placing a heavy strain on the cable and preventing the balloon from swinging violently. As is the case with practically everything used at the front, the technical name of the new type of balloon is prominent by its absence. It is a *Drache* (kite) to the Germans and a "blimp" to Tommy Atkins. Both its shape and attitude when aloft bear a close resemblance to a huge sausage, so that the term "sausage" is used by all the belligerents in common to a large extent. A side view of an American type is shown in Fig. 26.

[image]

*Fig. 25. Head-On View of Modern Kite Balloon, Showing Details of Tail Buckets*

*Copyright by Central News Service, New York City*

It will be noted from Figs. 25 and 26 that the suspension of the basket and the appendages attached to the balloon at the rear hold it in a position which is roughly the equivalent on a large scale of the curve of an aeroplane wing. It has both camber and an angle of incidence, so that the wind serves to elevate it instead of beating it down. This lifting effect is further increased by tubes of large diameter, open at the forward end only and curving around the end of the gas bag at the rear. (It is also equipped with an air balloonet, the same as a dirigible.) The wind enters the lower end of this tubular member, which is in a line with the longitudinal axis of the balloon, but it must pass around the curve at the end of the gas bag before it can fully inflate it, so that it performs the double function of increasing the lift and steadying the balloon, though the latter is its chief purpose. The basket is suspended quite a distance below the gas bag and has accommodation for two observers. Like scores of other inventions that the Germans were the first to utilize on a large scale in the present war, the kite balloon was not a German creation but was originally developed in France.

[image]

*Fig. 26. American Kite Balloon of Latest Type Ascending*

*Copyright by Committee on Public Information, Washington, D C.*

**Methods of Inflation.** The average capacity of the kite balloons used for

observation purposes is 28,000 cubic feet. They are inflated with hydrogen either from a portable generating plant forming part of the equipment of the balloon company or from a supply carried under high pressure in heavy steel "bottles" similar to those used for transporting oxygen or carbonic acid gas intended for industrial use. Since the balloon companies are stationed about 4 miles back of the firing line, the use of the portable plant is practical, but it has been found more economical and more convenient to generate the gas on a large scale at special establishments in France and England and send it to the front in containers. With a portable plant, several hours are necessary to inflate the gas bag, whereas with a large supply of the gas at hand under high pressure, the operation may be carried out in less than an hour.

The balloon naturally works under the same difficulties as all lighter-than-air craft, that is, there is a constant leakage of the hydrogen through the fabric in addition to that lost by the expansion of the gas on warm days when the summer sun beats down directly on the gas bag. Where a field generating plant is employed, quick inflation of a new balloon or replacement of loss is accomplished by the used of several "nurses", Fig. 27. These are simply large gas bags which are kept replenished by the gas plant working constantly, in other words, they are storage tanks, and when it is necessary to inflate the balloon quickly, their contents are simply transferred to it.

[image]

*Fig. 27. Landing Big Kite Balloon at Training Station "Somewhere in England." "Nurse" in Background  
Copyright by Underwood and Underwood, New York*

**Balloon Company.** Though aeronautical in character, the kite balloon service is actually a branch of the artillery, to which it is directly attached. A balloon company accordingly consists of twelve to twenty artillery officers of varying ranks and about 120 to 130 men. Of the officers, six to eight are artillery lieutenants or captains and go aloft as observers, this number being necessary because the strain of watching constantly is very great and the observers must be relieved at frequent intervals, the balloon otherwise being kept up continuously, both day and night. There are also a number of sergeants, each of whom is in charge of a different branch of the work, such as the inflation, transport, telephone service, and winding machine. No less than fifteen 3-ton to 5-ton motor trucks are necessary for each balloon company besides two or more motorcycle messengers, the care of the machines usually being entrusted to the corporals



of the company. The remainder of the company are practically laborers, whose chief duties are to attach the ballast bags to the ropes when it is intended to hold the balloon on the ground for any length of time and to utilize their own weight for the same purpose when the balloon is about to go aloft or is only on the ground temporarily. In addition, every company has its surgeon and assistants, quartermaster, cooks, company clerk, and other attaches necessary to complete its organization, since a balloon company serves as an independent unit.

**Equipment.** The paraphernalia required is quite as elaborate as that necessary to keep several aeroplanes aloft, though naturally of a different nature. It must all be readily portable, for a balloon company has to change camp more or less frequently, or as often as the enemy artillery happens to discover its range. To secure mobility is the purpose of the great number of motor trucks employed. One of these is equipped with a hoisting winch and a large drum capable of holding 3,000 or 4,000 feet of about 3/8-inch steel cable. The winch is driven by the same engine that propels the truck, and in case of emergency the engine may be applied to the two purposes alternately within a short space of time. For instance, in case of attack either by shrapnel from an enemy battery or by a hostile aviator, it may be used to quickly haul in or let out cable to change the altitude of the balloon, or it may be employed to drive the truck to another and more favorable location with the balloon in tow.

Another truck houses a complete telephone exchange, since the observers in the balloon may wish to communicate with any one of a number of batteries which they are serving. Telephone communication is established by means of an insulated wire which forms the core of the cable, while the steel cable itself acts as the return wire to complete the circuit. In some cases, a separate copper cable is employed, using the steel cable as the return half of the circuit. In addition there is a truck for transporting the balloons, for the company must always have duplicate equipment at hand in case of the destruction of the balloon it is using or, as more frequently happens, damage of a nature that requires hours or days to repair. In addition to the balloon itself, there are covers and the ground cloth, as in inflating a balloon no part of its fabric must be allowed to touch the ground because of the danger of stones or sticks tearing rents in it. The balloon proper and its immediate accessories utilize at least one and sometimes two motor trucks.

To hold the balloon on the ground when out of service, there are eighty sacks of sand weighing 25 pounds each, or an aggregate of 1 ton of ballast, in addition to which there are necessary a large number of steel screw stakes, spare ropes and parts, ladders and the like, besides the basket and its equipment. The stakes are employed to hold the balloon down in a heavy wind by "pegging" it in the same manner as a tent. Three or four trucks are required to carry the large supply of hydrogen necessary, which entails the transportation of 130 to

150 containers. Each container holds several thousand cubic feet of gas under high pressure, which is released through a reducing valve. Some of the other transportation units required are the "cook wagon," quartermaster's stores truck, truck for carrying tents, blankets, and other impediments for the men, and the "doctor's wagon" (ambulance).

**Advantages of Kite Balloon.** It became a necessity to resurrect the captive balloon and bring it up to date, not simply because the Germans were employing it in numbers, but because experience demonstrated that it possessed numerous advantages over the aeroplane for artillery observation. The observer in an aeroplane is carried back and forth over and around the location he wishes to watch, at high speed and at a constantly varying altitude. He must communicate by means of either signals or wireless, and it is not always possible for him in either case to know whether his signals have been received and understood, since it is possible to transmit messages by wireless from an aeroplane but a very difficult matter to receive. The observers in a kite balloon, on the other hand, have the advantage of being able to scrutinize a certain sector constantly with the aid of powerful glasses. With a few weeks of experience in observing a given terrain they become so familiar with it that any changes or the movements of troops or supplies are quickly distinguished. The greatest advantage, however, is that the information thus acquired may be instantly transmitted not merely to one but to any one or all of a group of batteries extending over a mile or two of front in either direction, the balloons being stationed 4 to 6 miles apart. The observers are fitted with portable head sets so that they speak directly into their telephones without the necessity of removing the glasses from their eyes, which enables them to watch the fall of the shells and tell the battery attendant in the dugout alongside the gun whether a shell fell "short", "over," "left," or "right," and the amount of correction needed before the smoke from the explosion has cleared away. With the aid of close corrections of this nature the battery commander is in a position to get the range exactly without the great expenditure of ammunition that firing entirely by map or with the assistance of aeroplane observers entails. Instances are recorded in which a 9.5-inch shell has been landed right in a concrete "pill-box" not over 15 feet square from a distance of 3 miles after six trial shots had been fired to obtain the range. Such a shot is reported back to the battery by the balloon observer as a "direct hit," and it is only necessary to fire the gun at the same range and direction to score as often as necessary.

**Duties of Balloon Crew.** Each kite balloon carries aloft two observers, Fig. 28, both of whom can concentrate their entire attention on the work of "spotting," since they have nothing to do with the control of the balloon itself, except to give orders. Their chief duties consist of "counter-battery" observation, that is, spotting the location of enemy batteries, and being constantly alert to detect any

suspicious movements back of the enemy's lines, such as movements of troops, ammunition, or supplies. The batteries controlled from observation balloons are the "heavies," which are located 1 mile or more back of the front line trenches and to the gunners of which the objects they are firing at are never visible. Some of the heaviest guns mounted on specially constructed railway trucks are often fired from points 5 miles or more back of the lines. In fact, when balked in their attempt to take Calais, the Germans bombarded the town with the aid of long-range naval guns from a distance of over 15 miles and every shot dropped into either some part of the city or its outskirts. Buildings, hills, or specially constructed and concealed observation towers are frequently utilized in conjunction with captive balloons to serve as auxiliary observation posts, so that the base line connecting the two may be used to triangulate distances and thus calculate them more accurately than is possible by direct observation from a single point.

[image]

*Fig. 28. French Kite Balloon Observers about to Ascend*  
 Copyright by Committee on Public Information, Washington, D.C.

**Risks Incurred. Enemy Fire.** While the observers in a kite balloon are not subjected to all the risks that the aviator must encounter when he goes aloft or, at least, not to the same extent, their lot is far from being free from danger. One of the duties of the reconnoitering aviator is to destroy observation balloons by means of incendiary bombs equipped with fishhooks which catch in the fabric or by the use of his machine gun. Enemy batteries may also succeed in getting the range of the balloon and fire at it with large caliber shrapnel, which spreads its fragments over an area 100 yards or more in diameter when it bursts. So many of the German balloons were downed by French and British aviators in the early part of the war—and the Germans retaliated in kind—that a battle plane is now always detailed to keep watch above the balloon to ward off attacks by aeroplanes.

*Escape of Balloon.* In addition to the risk of being shot down, there is the ever-present danger of the balloon being wrecked by a sudden squall or of its breaking away from its windlass through the parting of the cable and floating over the enemy lines. Balloons have been lost through both causes in a number of instances. Each of the two observers wears a heavy harness to which is attached a parachute suspended by a light cord from the rigging of the balloon, so that in case of emergency they may save themselves by jumping without having to make any preparations for their sudden drop.

In case of the breakage of the cable, which usually results from a strong wind coming up suddenly and putting a terrific strain on the steel line by jerking it, the observers are guided in their actions by the direction in which the balloon moves. When it is carrying them back over their own territory, they navigate in the same manner as a free balloon, coming to the ground as soon as a favorable landing place can be reached. Instruction in free ballooning is accordingly an important part of the curriculum that the kite balloon observers must go through. Should the wind be in the opposite direction, however, as only too often proves to be the case, all instruments, papers, and maps are immediately thrown over the side and the observers promptly follow suit in their parachutes, abandoning the balloon to its fate. As the balloon travels with the speed of the wind, once it is released, and the parachute of the descending observer is carried in the same direction, prompt action is vital to prevent coming to the ground in the enemy's territory. In a 30-mile wind, for example, only eight minutes would elapse from the moment that the balloon broke away until it traversed the 4 miles intervening between its station and the enemy's lines. On some occasions, kite balloons which were not fit for further service have been loaded with explosives and released from a height that would cause them to land well within the enemy's territory with disastrous results to the men detailed to capture them.

**Marine Service.** The kite balloon was first used by the British naval forces in their operations against the Dardanelles and proved so valuable that they have since been employed in fleet expeditions in the North Sea as well as for anti-submarine work. In the latter form of service, they have the same superiority over the aeroplane for observation that they possess in land operations. The ship naturally cannot run the risk of remaining stationary, but as the speed of the balloon is the same as that of the ship towing it, the observers do not pass over a given area with anything like the velocity of an aeroplane, while their elevated position affords the same advantages for detecting the presence of the submerged submarine or the approach of enemy vessels.

# EXAMINATION PAPER

## DIRIGIBLE BALLOONS

**Read Carefully:** Place your name and full address at the head of the paper. Any cheap, light paper like the sample previously sent you may be used. Do not crowd your work, but arrange it neatly and legibly. *Do not copy the answers from the Instruction Paper; use your own words, so that we may be sure you understand the subject.*

1. What essential features of design did Meusnier's first dirigible incorporate?
2. Describe the difference between rigid, semi-rigid, and flexible types of dirigibles.
3. State the laws governing the increase of resistance with speed, the increase of power necessary for a given increase of speed, and the ratio in which the volume and area of the gas bag increase with increased dimensions.
4. What provides the lifting power of the dirigible and how is this lifting power utilized? Why should this lifting power be so much less at night than in the daytime? What is net lifting power?
5. What are air balloonets? How and for what purpose are they used?
6. What is the most efficient form of envelope for the dirigible, and why?
7. Why cannot the ordinary spherical balloon be propelled as a dirigible?
8. Is the form of the stern as important as the bow?
9. What is longitudinal stability and how is it obtained?
10. How is stability of direction obtained? What are stabilizing planes?
11. Why must a form of suspension for the car that cannot be accidentally displaced with relation to the balloon be provided?
12. Theoretically, where should the propulsive effort be applied to a dirigible? What factors affect the placing of the propeller and what has been proved to be the most practical solution of the problem?
13. Discuss the advantages of the kite balloon over the aeroplane for observation.

14. What is the effect of the wind on a modern kite balloon?
15. What is the difference between "pounds per horsepower" and "pounds per horsepower hour" as applied to the motor of a dirigible? Which is more important?
10. Sketch and explain the Astra-Torres suspension.
17. What differences exist between a Zeppelin and a Schutte-Lanz dirigible?
18. Describe the "L-49", discussing power plant and control.
19. Define static and dynamic equilibrium as applied to the dirigible.
20. Is the Zeppelin effective? Discuss fully.

**After completing the work, add and sign the following statement:**

I hereby certify that the above work is entirely my own.  
(Signed)





\*\*\* END OF THIS PROJECT GUTENBERG EBOOK DIRIGIBLE BALLOONS \*\*\*



## A Word from Project Gutenberg

We will update this book if we find any errors.

This book can be found under: <https://www.gutenberg.org/ebooks/63234>

Creating the works from print editions not protected by U.S. copyright law means that no one owns a United States copyright in these works, so the Foundation (and you!) can copy and distribute it in the United States without permission and without paying copyright royalties. Special rules, set forth in the General Terms of Use part of this license, apply to copying and distributing Project Gutenberg™ electronic works to protect the Project Gutenberg™ concept and trademark. Project Gutenberg is a registered trademark, and may not be used if you charge for the eBooks, unless you receive specific permission. If you do not charge anything for copies of this eBook, complying with the rules is very easy. You may use this eBook for nearly any purpose such as creation of derivative works, reports, performances and research. They may be modified and printed and given away – you may do practically *anything* in the United States with eBooks not protected by U.S. copyright law. Redistribution is subject to the trademark license, especially commercial redistribution.

# The Full Project Gutenberg License

*Please read this before you distribute or use this work.*

To protect the Project Gutenberg™ mission of promoting the free distribution of electronic works, by using or distributing this work (or any other work associated in any way with the phrase “Project Gutenberg”), you agree to comply with all the terms of the Full Project Gutenberg™ License available with this file or online at <https://www.gutenberg.org/license>.

## Section 1. General Terms of Use & Redistributing Project Gutenberg™ electronic works

1.A. By reading or using any part of this Project Gutenberg™ electronic work,

you indicate that you have read, understand, agree to and accept all the terms of this license and intellectual property (trademark/copyright) agreement. If you do not agree to abide by all the terms of this agreement, you must cease using and return or destroy all copies of Project Gutenberg™ electronic works in your possession. If you paid a fee for obtaining a copy of or access to a Project Gutenberg™ electronic work and you do not agree to be bound by the terms of this agreement, you may obtain a refund from the person or entity to whom you paid the fee as set forth in paragraph 1.E.8.

1.B. “Project Gutenberg” is a registered trademark. It may only be used on or associated in any way with an electronic work by people who agree to be bound by the terms of this agreement. There are a few things that you can do with most Project Gutenberg™ electronic works even without complying with the full terms of this agreement. See paragraph 1.C below. There are a lot of things you can do with Project Gutenberg™ electronic works if you follow the terms of this agreement and help preserve free future access to Project Gutenberg™ electronic works. See paragraph 1.E below.

1.C. The Project Gutenberg Literary Archive Foundation (“the Foundation” or PGLAF), owns a compilation copyright in the collection of Project Gutenberg™ electronic works. Nearly all the individual works in the collection are in the public domain in the United States. If an individual work is unprotected by copyright law in the United States and you are located in the United States, we do not claim a right to prevent you from copying, distributing, performing, displaying or creating derivative works based on the work as long as all references to Project Gutenberg are removed. Of course, we hope that you will support the Project Gutenberg™ mission of promoting free access to electronic works by freely sharing Project Gutenberg™ works in compliance with the terms of this agreement for keeping the Project Gutenberg™ name associated with the work. You can easily comply with the terms of this agreement by keeping this work in the same format with its attached full Project Gutenberg™ License when you share it without charge with others.

1.D. The copyright laws of the place where you are located also govern what you can do with this work. Copyright laws in most countries are in a constant state of change. If you are outside the United States, check the laws of your country in addition to the terms of this agreement before downloading, copying, displaying, performing, distributing or creating derivative works based on this work or any other Project Gutenberg™ work. The Foundation makes no representations concerning the copyright status of any work in any country outside the United States.

1.E. Unless you have removed all references to Project Gutenberg:

1.E.1. The following sentence, with active links to, or other immediate ac-

cess to, the full Project Gutenberg™ License must appear prominently whenever any copy of a Project Gutenberg™ work (any work on which the phrase “Project Gutenberg” appears, or with which the phrase “Project Gutenberg” is associated) is accessed, displayed, performed, viewed, copied or distributed:

This eBook is for the use of anyone anywhere in the United States and most other parts of the world at no cost and with almost no restrictions whatsoever. You may copy it, give it away or re-use it under the terms of the Project Gutenberg License included with this eBook or online at <https://www.gutenberg.org> . If you are not located in the United States, you'll have to check the laws of the country where you are located before using this ebook.

1.E.2. If an individual Project Gutenberg™ electronic work is derived from texts not protected by U.S. copyright law (does not contain a notice indicating that it is posted with permission of the copyright holder), the work can be copied and distributed to anyone in the United States without paying any fees or charges. If you are redistributing or providing access to a work with the phrase “Project Gutenberg” associated with or appearing on the work, you must comply either with the requirements of paragraphs 1.E.1 through 1.E.7 or obtain permission for the use of the work and the Project Gutenberg™ trademark as set forth in paragraphs 1.E.8 or 1.E.9.

1.E.3. If an individual Project Gutenberg™ electronic work is posted with the permission of the copyright holder, your use and distribution must comply with both paragraphs 1.E.1 through 1.E.7 and any additional terms imposed by the copyright holder. Additional terms will be linked to the Project Gutenberg™ License for all works posted with the permission of the copyright holder found at the beginning of this work.

1.E.4. Do not unlink or detach or remove the full Project Gutenberg™ License terms from this work, or any files containing a part of this work or any other work associated with Project Gutenberg™.

1.E.5. Do not copy, display, perform, distribute or redistribute this electronic work, or any part of this electronic work, without prominently displaying the sentence set forth in paragraph 1.E.1 with active links or immediate access to the full terms of the Project Gutenberg™ License.

1.E.6. You may convert to and distribute this work in any binary, compressed, marked up, nonproprietary or proprietary form, including any word processing or hypertext form. However, if you provide access to or distribute copies of a Project Gutenberg™ work in a format other than “Plain Vanilla ASCII” or other format used in the official version posted on the official Project Guten-

berg™ web site (<https://www.gutenberg.org>), you must, at no additional cost, fee or expense to the user, provide a copy, a means of exporting a copy, or a means of obtaining a copy upon request, of the work in its original “Plain Vanilla ASCII” or other form. Any alternate format must include the full Project Gutenberg™ License as specified in paragraph 1.E.1.

1.E.7. Do not charge a fee for access to, viewing, displaying, performing, copying or distributing any Project Gutenberg™ works unless you comply with paragraph 1.E.8 or 1.E.9.

1.E.8. You may charge a reasonable fee for copies of or providing access to or distributing Project Gutenberg™ electronic works provided that

- You pay a royalty fee of 20% of the gross profits you derive from the use of Project Gutenberg™ works calculated using the method you already use to calculate your applicable taxes. The fee is owed to the owner of the Project Gutenberg™ trademark, but he has agreed to donate royalties under this paragraph to the Project Gutenberg Literary Archive Foundation. Royalty payments must be paid within 60 days following each date on which you prepare (or are legally required to prepare) your periodic tax returns. Royalty payments should be clearly marked as such and sent to the Project Gutenberg Literary Archive Foundation at the address specified in Section 4, “Information about donations to the Project Gutenberg Literary Archive Foundation.”
- You provide a full refund of any money paid by a user who notifies you in writing (or by e-mail) within 30 days of receipt that s/he does not agree to the terms of the full Project Gutenberg™ License. You must require such a user to return or destroy all copies of the works possessed in a physical medium and discontinue all use of and all access to other copies of Project Gutenberg™ works.
- You provide, in accordance with paragraph 1.F.3, a full refund of any money paid for a work or a replacement copy, if a defect in the electronic work is discovered and reported to you within 90 days of receipt of the work.
- You comply with all other terms of this agreement for free distribution of Project Gutenberg™ works.

1.E.9. If you wish to charge a fee or distribute a Project Gutenberg™ electronic work or group of works on different terms than are set forth in this agreement, you must obtain permission in writing from both the Project Gutenberg Literary Archive Foundation and The Project Gutenberg Trademark LLC, the owner of the

Project Gutenberg™ trademark. Contact the Foundation as set forth in Section 3. below.

1.F.

1.F.1. Project Gutenberg volunteers and employees expend considerable effort to identify, do copyright research on, transcribe and proofread works not protected by U.S. copyright law in creating the Project Gutenberg™ collection. Despite these efforts, Project Gutenberg™ electronic works, and the medium on which they may be stored, may contain “Defects,” such as, but not limited to, incomplete, inaccurate or corrupt data, transcription errors, a copyright or other intellectual property infringement, a defective or damaged disk or other medium, a computer virus, or computer codes that damage or cannot be read by your equipment.

1.F.2. LIMITED WARRANTY, DISCLAIMER OF DAMAGES – Except for the “Right of Replacement or Refund” described in paragraph 1.F.3, the Project Gutenberg Literary Archive Foundation, the owner of the Project Gutenberg™ trademark, and any other party distributing a Project Gutenberg™ electronic work under this agreement, disclaim all liability to you for damages, costs and expenses, including legal fees. YOU AGREE THAT YOU HAVE NO REMEDIES FOR NEGLIGENCE, STRICT LIABILITY, BREACH OF WARRANTY OR BREACH OF CONTRACT EXCEPT THOSE PROVIDED IN PARAGRAPH 1.F.3. YOU AGREE THAT THE FOUNDATION, THE TRADEMARK OWNER, AND ANY DISTRIBUTOR UNDER THIS AGREEMENT WILL NOT BE LIABLE TO YOU FOR ACTUAL, DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE OR INCIDENTAL DAMAGES EVEN IF YOU GIVE NOTICE OF THE POSSIBILITY OF SUCH DAMAGE.

1.F.3. LIMITED RIGHT OF REPLACEMENT OR REFUND – If you discover a defect in this electronic work within 90 days of receiving it, you can receive a refund of the money (if any) you paid for it by sending a written explanation to the person you received the work from. If you received the work on a physical medium, you must return the medium with your written explanation. The person or entity that provided you with the defective work may elect to provide a replacement copy in lieu of a refund. If you received the work electronically, the person or entity providing it to you may choose to give you a second opportunity to receive the work electronically in lieu of a refund. If the second copy is also defective, you may demand a refund in writing without further opportunities to fix the problem.

1.F.4. Except for the limited right of replacement or refund set forth in paragraph 1.F.3, this work is provided to you ‘AS-IS,’ WITH NO OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PUR-

POSE.

1.F.5. Some states do not allow disclaimers of certain implied warranties or the exclusion or limitation of certain types of damages. If any disclaimer or limitation set forth in this agreement violates the law of the state applicable to this agreement, the agreement shall be interpreted to make the maximum disclaimer or limitation permitted by the applicable state law. The invalidity or unenforceability of any provision of this agreement shall not void the remaining provisions.

1.F.6. INDEMNITY – You agree to indemnify and hold the Foundation, the trademark owner, any agent or employee of the Foundation, anyone providing copies of Project Gutenberg™ electronic works in accordance with this agreement, and any volunteers associated with the production, promotion and distribution of Project Gutenberg™ electronic works, harmless from all liability, costs and expenses, including legal fees, that arise directly or indirectly from any of the following which you do or cause to occur: (a) distribution of this or any Project Gutenberg™ work, (b) alteration, modification, or additions or deletions to any Project Gutenberg™ work, and (c) any Defect you cause.

## **Section 2. Information about the Mission of Project Gutenberg™**

Project Gutenberg™ is synonymous with the free distribution of electronic works in formats readable by the widest variety of computers including obsolete, old, middle-aged and new computers. It exists because of the efforts of hundreds of volunteers and donations from people in all walks of life.

Volunteers and financial support to provide volunteers with the assistance they need, is critical to reaching Project Gutenberg™'s goals and ensuring that the Project Gutenberg™ collection will remain freely available for generations to come. In 2001, the Project Gutenberg Literary Archive Foundation was created to provide a secure and permanent future for Project Gutenberg™ and future generations. To learn more about the Project Gutenberg Literary Archive Foundation and how your efforts and donations can help, see Sections 3 and 4 and the Foundation web page at <https://www.pgla.org> .

## **Section 3. Information about the Project Gutenberg Literary Archive Foundation**

The Project Gutenberg Literary Archive Foundation is a non profit 501(c)(3) educational corporation organized under the laws of the state of Mississippi and



granted tax exempt status by the Internal Revenue Service. The Foundation's EIN or federal tax identification number is 64-6221541. Contributions to the Project Gutenberg Literary Archive Foundation are tax deductible to the full extent permitted by U.S. federal laws and your state's laws.

The Foundation's principal office is in Fairbanks, Alaska, with the mailing address: PO Box 750175, Fairbanks, AK 99775, but its volunteers and employees are scattered throughout numerous locations. Its business office is located at 809 North 1500 West, Salt Lake City, UT 84116, (801) 596-1887, email [business@pglaf.org](mailto:business@pglaf.org). Email contact links and up to date contact information can be found at the Foundation's web site and official page at [www.gutenberg.org/contact](http://www.gutenberg.org/contact)

For additional contact information:

Dr. Gregory B. Newby  
Chief Executive and Director  
[gbnewby@pglaf.org](mailto:gbnewby@pglaf.org)

## **Section 4. Information about Donations to the Project Gutenberg Literary Archive Foundation**

Project Gutenberg™ depends upon and cannot survive without wide spread public support and donations to carry out its mission of increasing the number of public domain and licensed works that can be freely distributed in machine readable form accessible by the widest array of equipment including outdated equipment. Many small donations (\$1 to \$5,000) are particularly important to maintaining tax exempt status with the IRS.

The Foundation is committed to complying with the laws regulating charities and charitable donations in all 50 states of the United States. Compliance requirements are not uniform and it takes a considerable effort, much paperwork and many fees to meet and keep up with these requirements. We do not solicit donations in locations where we have not received written confirmation of compliance. To SEND DONATIONS or determine the status of compliance for any particular state visit <https://www.gutenberg.org/donate>

While we cannot and do not solicit contributions from states where we have not met the solicitation requirements, we know of no prohibition against accepting unsolicited donations from donors in such states who approach us with offers to donate.

International donations are gratefully accepted, but we cannot make any

statements concerning tax treatment of donations received from outside the United States. U.S. laws alone swamp our small staff.

Please check the Project Gutenberg Web pages for current donation methods and addresses. Donations are accepted in a number of other ways including checks, online payments and credit card donations. To donate, please visit: <https://www.gutenberg.org/donate>

## **Section 5. General Information About Project Gutenberg™ electronic works.**

Professor Michael S. Hart was the originator of the Project Gutenberg™ concept of a library of electronic works that could be freely shared with anyone. For thirty years, he produced and distributed Project Gutenberg™ eBooks with only a loose network of volunteer support.

Project Gutenberg™ eBooks are often created from several printed editions, all of which are confirmed as not protected by copyright in the U.S. unless a copyright notice is included. Thus, we do not necessarily keep eBooks in compliance with any particular paper edition.

Most people start at our Web site which has the main PG search facility:

<https://www.gutenberg.org>

This Web site includes information about Project Gutenberg™, including how to make donations to the Project Gutenberg Literary Archive Foundation, how to help produce our new eBooks, and how to subscribe to our email newsletter to hear about new eBooks.